

User Manual

Precision Impedance Analyzer

6632

S/W Ver	Firmware Ver	Date
1.38	21.1130	May-2023



MICROTEST



Microtest



Youtube



FaceBook

Copyright and Trademark

Do not attempt to reproduce any part of this publication or transmit it by any form or method, whether through electronic, mechanical, copying, recording or other means, without the prior written permission of Microtest Co., Ltd. We shall neither be subjected to any responsibilities or obligations for the information contained in this Manual nor do bear damage responsibility resulting from the use of the information contained herein. All brands and trademark are the properties of Microtest Co., Ltd. Microtest Co., Ltd. and its affiliates shall not be liable for the damage, losses or costs incurred due to the accidental use, misuse or abuse by the product buyer or the third party; or the unauthorized modification, repairs or change of the product; or the failure in following the operation and maintenance instructions established by Microtest. The content and the product specifications shall be subject to change without further notice.

2020 @ Microtest Corporation. All rights reserved.

CONTENT

CHAPTER 1 SAFETY SPECIFICATION	2
1.1 SAFETY MARKS (THE FOLLOWING SAFETY MARKS MAY APPEAR IN THIS MANUAL)	2
CHAPTER 2 PREFACE	5
2.1 INTRODUCTION	5
2.2 KEY FEATURE	5
2.3 SPECIFICATION	7
CHAPTER 3 DESCRIPTION OF INSTALLATION	10
3.1 PACKAGE & EQUIPMENT	10
3.2 DESCRIPTION OF FUNCTION KEYS ON FRONT PANEL	11
3.3 DESCRIPTION OF FUNCTION KEYS ON BACK PANEL	12
3.4 HARDWARE INSTALLATION	12
CHAPTER 4 BASIC MEASURING	20
4.1 METER MODE	20
4.2 FREQ(FREQUENCY)	20
4.3 LEVEL	20
4.4 RANGE AC	20
4.5 SPEED	21
4.6 BIAS	21
4.7 RANGE DC	21
4.8 TRIG	21
4.9 COMP	21
4.10 PARAMETERS	22
4.11 MEASURER MODE SETUP	23
4.12 TRIGGER MODE	25
4.13 LEVEL/RO/ALC	25
4.14 SET E_R	26
4.15 DIELECTRIC COEFFICIENT MEASUREMENT METHOD	27
4.16 SET M_R	27
4.17 MAGNETIC PERMEABILITY COEFFICIENT MEASUREMENT METHOD	28
4.18 COMP (COMPARISON)	28
4.19 BIN SETUP	30
4.20 FILE	34
CHAPTER 5 LIST TEST	36
5.1 LIST SET	36
5.2 LIST MODE SETUP	37
5.3 CORR.(LIST CORRECTION)	39
CHAPTER 6 SWEEP	40
6.1 SWEEP MODE SETUP	40
6.2 EQUIVALENT CIRCUIT ANALYSIS (OPTION)	47
CHAPTER 7 CORRECTION	49
7.1 OPEN CIRCUIT CORRECTION	50
7.2 SHORT CIRCUIT CORRECTION	51
7.3 HF LOAD	52

7.4	SPOT LOAD	52
7.5	CABLE LENGTH	52
7.6	FIXTURE COMPENSATION	53
7.7	SPOT. NO.	53
7.8	FREQUENNCY	53
7.9	LOAD FUNCTION	54
7.10	REFERENCE	54
7.11	LOAD	54
CHAPTER 8 SYSTEM CONFIG		55
8.1	LANGUAGE	55
8.2	GPIB ADDRESS	56
8.3	RS232 BAUD RATE	56
8.4	RS232 EOI	56
8.5	LAN PORT	56
8.6	HANDLERINTERFACE	56
8.7	KEY BEEP	56
8.8	BIAS RESOURCE	56
CHAPTER 9 APPENDIX		61
9.1	Z ACCURACY CHART	61
9.2	MEASUREMENT ACCURACY	62
CHAPTER 10 CONCEPT OF COMMAND		63

Chapter 1 Safety Specification

This instrument is designed according to EN61010-1 Specification. The main purpose of this Specification is to ensure that the instrument will be used in the laboratory or the factory safely; it is not suitable for outdoor applications, especially the moistened or dusty locations. Abnormal use of this instrument may cause the electrocution hazard. Before using this instrument, please read the descriptions of this Specification carefully to avoid causing accident due to incorrect or unintended use.

1.1 Safety marks (the following safety marks may appear in this Manual)



Caution:

Please read the content of this Manual carefully.



High-voltage hazard symbol:

The output terminal may release lethal voltage. Please read the safety instructions described in this chapter.



Grounding:

Before working with this tester, be sure to connect this terminal with the ground to prevent from touching the housing as to cause electrocution accident due to current leakage.



Warning sign:

If the product is improperly used, it may cause adverse result to the instrument or the Test Piece. If the product is improperly used, it may cause injury or even death.

1.2 Electrocution

To prevent electrocution accident from occurring, it is suggested that the operator wear insulating rubber globes before working with the machine and then start the test-related activities.

1.3 Grounding

The back panel of the instrument is fitted with a safe ground terminal. Be sure to connect this ground terminal to the ground to prevent the operator from touching the housing as to cause the electrocution.

1.4 Power Source

The scope of power used by this instrument is 88~264Vac. To insert the power source, please check if the power to be connected is identical with the power-shifting sign indicated on the back panel. When changing the fuse, it is required to use specific type of fuse designed in same ampere to prevent the electrical wire from burning. Before making any replacement, please remove the plug to prevent danger.

1.5 Warm-up

The instrument will operate normally upon starting the power. To achieve the specified accuracy, it is suggested warming up the instrument for over 15 minutes

1.6 External control unit

This unit is able to execute the external control. For this purpose, please ensure that the operator is not touching the signal output end and the Test Piece to avoid causing hazard.

1.7 Machine failure

Stop using the instrument immediately when finding it is operating abnormally, such as significant difference is existed between the current displayed on the current meter and the design value; or the current is not supplied, but the overlapping current indicator remains illuminated continuously. In this case, please contact us or your dealer to provide technical support.

1.8 Ending the test

When not using the instrument, please shut off the Power Switch. To restart the Power Switch after being disconnected, please wait for few seconds; however, do not execute consecutive on/off action of the power.

1.9 Installation, storage

Normal operating temperature and humidity scope of the instrument is 5oC~40oC and 80% RH respectively, and the instrument may act abnormally if exceeding such range. The storage temperature and humidity scope of the instrument is -20oC~ 70oC and 80% RH respectively. To achieve correct testing and to protect safety, do not install the instrument in the environment exposing to direct sunshine or high temperature, high humidity, frequency oscillation and rich dust.

1.10 Emergency treatment

Upon the occurrence of electrocution, burning of the Test Piece or the burning of Main Unit, please disconnect the Power Switch and remove the power cord plug immediately to avoid causing a hazard.

1.11 General instructions

- Do not place any combustible or heavy object on the instrument.
- Avoid heavy impact that may damage the machine.
- When cleaning the instrument, remove the power plug first and then wipe with the soft cloth soaked with mild cleanser and fresh water.
- If the instrument presents any Tolerance sign, do not attempt to dismantle it for making repairs; instead, send the instrument to our professional maintenance personnel for solving the problem.

Chapter 2 Preface

In this chapter, we briefly introduce the characters, key features and specifications of 6632 Precision Impedance Analyzer.

2.1 Introduction

The test frequency of the 6632 Precision Impedance Analyzer is DC 10Hz-30MHz and the test signal is 10mV-2Vrms (min. resolution 1mV), and is suitable for the LCR and DCR testes of AC signals. The measurement in a continuously changing environment can be executed stage-by-stage with the test frequency and grade, and high-speed continuous tests can be performed under different test and mode conditions. The machine also supports LAN, USB and GPIB PC connection capabilities to improve the design and test efficiency significantly. MICROTTEST 6632 Impedance Analyzer also provides fixtures for material dielectric permittivity measurement that allows PCB designed engineers to reduce the faulty conditions with the comprehensive information of permittivity while designing PCB layouts.

The performance, convenience and operation flexibility of the Precision Impedance Analyzer have become indispensable tools for the professional measuring technicians. In addition to providing full-range solutions for the testing equipment over the past years, Microtest also developed the new model of “6632 Precision Impedance Analyzer” that has contributed to more perfect precision solutions for the test. Such analyzer can meet customer demands for price, speed, capacity, accuracy and multi-function by its well-based flexibility in combination and implementation. Therefore, it can be used in the testing of a variety of components such as resistor, capacitor, inductor, oscillator, sensor, time-delay wire, filter and resonator.

2.2 Key Feature

- Signal source frequency range: DC, 10Hz ~ 3/5/10/20/30/50MHz
- Signal source grade: 10mV ~ 2V / 100μA ~ 20mA
- Basic accuracy up to $\pm 0.08\%$ (Typical value $\pm 0.05\%$)
- ALC function
- Output resistance 25Ω/100Ω, switchable
- Ultra-high measuring speed (<3ms MAX)
- Open circuit/short circuit/load calibration function
- Electric meter mode, multistep list mode, scan & analyze mode
- Build-in DC bias voltage $\pm 12V$
- Accurately measure the admittance circle drawing of piezoelectric ceramic materials, and provide the C-V curve for measuring capacitance
- Up to four component parameters can be selected in the electric meter mode. The induction and DCR values can be measured and displayed simultaneously
- Auto component classification: Comparator function and Handler BIN classification function

- It can be matched with various fixtures, such as: dielectric, liquid dielectric and permeability fixture
- Can be equipped with DC bias current source test system (6243)
- Up to 32 sets of multistep list programs can be stored in the permanent memory and up to 16 test steps can be arranged in each program
- Rapid automation and data access function is realizable for USB, LAN, GPIB and RS232 interfaces
- Suitable for R&D, manufacturing process, laboratory and other testing fields
- PC connection data analysis software is available optionally
- 7" 800*480 TFT LCD color screen
- Ultra-light design: 344x145x343mm, 3kg
- Ultra-low power consumption (<30W) without fans and zero noise

2.3 Specification

6632 Precision Impedance					
Models	Frequency range	Meter	List mode	Sweep mode	Equivalent circuit
6632-50S	10Hz~ 50MHz	✓	✓	✓	✓
6632-30S	10Hz~ 30MHz	✓	✓	✓	✓
6632-20S	10Hz~ 20MHz	✓	✓	✓	✓
6632-10S	10Hz~ 10MHz	✓	✓	✓	✓
6632-5S	10Hz~ 5MHz	✓	✓	✓	✓
6632-3S	10Hz~ 3MHz	✓	✓	✓	✓
6632-1S	10Hz~ 1MHz	✓	✓	✓	✓
6632-50	10Hz~ 50MHz	✓	✓	✓	
6632-30	10Hz~ 30MHz	✓	✓	✓	
6632-20	10Hz~ 20MHz	✓	✓	✓	
6632-10	10Hz~ 10MHz	✓	✓	✓	
6632-5	10Hz~ 5MHz	✓	✓	✓	
6632-3	10Hz~ 3MHz	✓	✓	✓	
6632-1	10Hz~ 1MHz	✓	✓	✓	
Resolution	100mHz, 6-bit Frequency Input				
Accuracy	±0.01 %				
Basic Accuracy	±0.08% (Typical value ±0.05%)				
Display Range	DCR	0.00mΩto99.9999MΩ			
	Z	0.000mΩto9999.99MΩ			
	R, X	±0.000mΩto9999.99MΩ			
	Y	0.00000μSto999.999kS			
	G, B	±0.00000μSto999.999kS			
	Cs, Cp	±0.00000pFto9999.99F			
	Ls, Lp	±0.00nHto9999.99kH			
	Q	0.00to9999.99			
	D	0.00000to9999.99			
	θ _{DEG}	±0.000°to180.000°			
	θ _{RAD}	±0.00000 to 3.14159			
	Δ%	±0.000%to999.999%			

Voltage Signal Level *f: frequency [MHz]	Range	10mV~2Vrms (f ≤ 1 MHz) 10mV~1Vrms (f > 1MHz or f ≤1 MHz and RO=25Ω)	
	Resolution	1mV	
	Accuracy		
	4-Terminal test fixture Cable length > 0m	± [(10 + 0.05 × f) % + 1 mV] ± [(15 + 0.1 × f)% + 1 mV]	
Current Signal Level *f: frequency [MHz]	Range	100μA ~ 20mArms (RO=100Ω) 400μA ~ 40mArms (RO=25Ω)	
	Resolution	10μA	
	Accuracy		
	4-Terminal test fixture at f ≤ 15MHz at f > 15MHz Cable length > 0m at f ≤ 5MHz at f > 15MHz	+ [10% + 50 μA], – [(10 + 0.2 × f ²) % + 50 μA] ± [(10 + 0.3 × f) % + 50 μA] + [10% + 50 μA], – [(15 + 1.5 × f ²) % + 50 μA] ± [(20 + 0.3 × f) % + 50 μA]	
Measurement Time	<3ms(The fastest)		
Output Resistance	25Ω/100Ω, switchable		
Parameter	Z 、 Y 、θ、X、R、G、B、L、D、Q、DCR、C、Vdc-Idc、ESR、ε、μ		
Calibration	Open Circuit/ Short Circuit/ Load Calibration		
Measurement	Series/ Parallel		
Multi-steps Mode	50 setup groups (with each group containing 15 measuring steps)		
PCLINK CPK Equivalent Circuit Analysis	Option		
Flash Memory	100 LCR-measure Mode setup documents& 50 Multi-steps Mode setup		
USB Memory	LCR-measure Mode setup document、Multi-steps Mode setup document、BMP graphics、Test result data、Sweep Mode BMP graphics& result data		
Interface	I/O Interface	Handler	
	Parallel interface	USB、RS232	
	Serial interface	GPIB	
Display	7.0” TFT, 800*480color screen		
Environment	+10°C~+40°C,20~80%RH		
Storage	-10°C~+60°C,20~80%RH		
Power Supply	Voltage	90~264Vac	
	Frequency	47~63Hz	
Power	Low power consumption: Maximum 30W (Nominal value)		
Dimension(W*H*D)	336x147x340mm		

Weight	3.95kg
--------	--------

Chapter 3 Description of Installation

Thank you for using Microtest 6632 Precision Impedance Analyzer as your testing instrument. This Manual contains the detailed installation steps. To ensure personnel safety and to protect your equipment and data, please check if the following accessories are fully supplied before starting the installation.

3.1 Package & Equipment

Standard:

If you are missing the following standard accessories, please contact your purchase manufacturer before installation.

- 6632 Precision Impedance Analyzer x 1
- Power cord & Power line adapter x 1
- FX-000C19 High frequency DIP fixture x 1

Optional:

- PC software
- F423906A (Kelvin Clip Leads with BNC Box)
- F663001 Type-A/B/C (BNC Test extension cord)
- FX-0000C6 (High frequency DIP fixture)
- FX-0000C7 (Dielectric Material Test Fixture)
- FX-0000C8 (Magnetic Material Test Fixture)
- FX-0000C9 (Material Test Fixture)
- FX-000C10 (Bottom Electrode SMD Test Fixture)
- FX-000C11 (SMD Tweezers Test Leads)
- FX-000C12 (SMD Test Fixture)
- FX-000C20 (Liquid Dielectric Material Test Fixture)
- F423503 (DIP elements test fixture)
- F420001 (External voltage bias fixture $\pm 200\text{V}/1\text{MHz}$)
- F420004 (External voltage bias fixture $\pm 600\text{V}/1\text{MHz}$)
- F420005 (External voltage/ current bias fixture $\pm 40\text{V}/100\text{mA}$)
- F420006 (External voltage bias fixture $\pm 2000\text{V}/1\text{MHz}$)

※ External current bias instrument (refer to 8.8 BIAS Resource)

1. 6210/6220/6240 (Support frequency up to 3MHZ)
2. 6223/6243 (Support frequency up to 10MHZ)
3. 6225 (Support frequency up to 30MHZ)

Application:

Measuring power and discharge inductance, common mode inductance, integral molding inductance, charging gun high-power components, electric vehicle turbocharging system, electric vehicle on-board system

3.2 Description of function keys on front panel





Figure 3.2.1 Front panel

Push Key and Port	Function
1. Enter	Enter key
2. Exit	Exit key
3. Number key	Input value
4. Menu	For selecting Meter, Multi-step, Trace, Trim and System modes, etc.
5. Local	GPIB computer remote control wire. Such key will be locked to prevent from controlling the push key and the computer by both sides. To use the keypad again, press this key again.
6. Bias	For connecting the Bias unit and for executing on/off.
7. Trigger	For starting the test. When the instrument is under single-mode testing status, press “Trigger” to obtain the result of such test and the instrument will stop the testing action, waiting for next starting or other function change.
8. Direction	For selecting menu items. The “Up/Down/Left/Right” key set and control the cursor movement on the screen.
9. Function	For executing the function indicated for the position corresponding to the Function key.
10.LCUR (BNC)	BNC terminal
11.LPOT (BNC)	
12.H POT (BNC)	
13.H CUR (BNC)	
14.Ground Terminal	Grounding
15.LCD	Display
16.USB	For accessing data and image.
17.Power	Power Switch

3.3 Description of function keys on back panel



*Rear view (millimeters)


PORT	FUNCTION
1. Handler	Pass/Fail signal (see 3.4.3 Handler Interface)
2. RS232	For connecting to software port (see 3.4.2 RS232 Connecting)
3. GPIB	Remote control port: 24-pin block (see 3.4.1 GPIB Connecting)
4. EXT. I/O	For expanding Bias Input/Output port
5. Trigger	Pedal Switch port
6. USB	For software copying and upgrading
7. LAN	Network port
8. Power jack Fuse block	AC power for 90~264V / 47~63Hz The fuse block contains input power fuse T3A/250V

3.4 Hardware Installation

3.4.1 GPIB Connecting

The computer and the measuring instrument are connected with GPIB (General-Purpose Interface Bus) cable, and the Test Piece will be tested or trimmed on the computer through GPIB.

- Definition of GPIB Pin



Pin	Definition	Pin	Definition
1	Dataline1	13	Dataline5
2	Dataline2	14	Dataline6
3	Dataline3	15	Dataline7
4	Dataline4	16	Dataline8
5	EOI	17	REN
6	DAV	18	Ground
7	NRFD	19	Ground
8	NDAC	20	Ground
9	IFC	21	Ground
10	SRQ	22	Ground
11	ATN	23	Ground
12	Shield	24	Signal ground


✂ Restrictions of GPIB:

- At most, 15 units of equipment can be connected at the same time. The total length of connecting cable will be 20m, and the connecting cable between each equipment is 2m long.
- Each piece of equipment will be allocated with a specific position.
- Min. 2/3 of equipment will be operating.
- The equipment will be connected by non-loop or parallel method.

3.4.2 RS232 Connecting

The computer and the measuring instrument are connected through RS232, and the Test Piece will be tested or trimmed on the computer through RS232.

- Definition of RS232Pin




Pin	Definition	Pin	Definition
1	Non-connection	6	Non-connection
2	RXD (receiving data)	7	Non-connection
3	TXD (transmitting data)	8	Non-connection
4	Non-connection	9	Non-connection
5	GND		

3.4.3 Handler Interface

You may control the test function of your machine with an external signal through the Handler Interface and Handler I/O port in its back panel.

Please set the Handler Interface ON in SYSTEM menu to enable remote control and set the dip switch to on (both switches are pull down).



- Pins in Handler I/O port:



PIN #	Signal Name			Logic	Function Description
	Meter mode	List mode	Meter/List mode		
	(BIN off)		(BIN on)		
1	/EXT_TRIG			I Negative, Edge	External trigger signal, pulse width $\geq 100 \mu s$
2	/EOM			O Negative, Level	"End of all measurement" signal
3	/PASS			O Negative, Level	Pass signal of comparator
4	/FAIL			O Negative, Level	Fail signal of comparator
5	Trig Return			Signal Return	External Trigger Signal Return
6	COM			Common ground	Common ground of result signal
7	COM			Common ground	Common ground of result signal
8	--			--	
9	--			--	
10	+5V out			O DC_Power Out	+5V Supply, 100 mA max
11	--			--	
12	--			--	
13	/Ready			O Negative, Level	"Ready for trigger" signal
14	/Index			O Negative, Level	"End of analog measurement" signal
15	/PARA-1 OK	/STEP-1 OK	/BIN1	O Negative, Level	Comparator or Bin judgment result
16	/PARA-2 OK	/STEP-2 OK	/BIN2	O Negative, Level	Comparator or Bin judgment result
17	/PARA-3 OK	/STEP-3 OK	/BIN3	O Negative, Level	Comparator or Bin judgment result
18	/PARA-4 OK	/STEP-4 OK	/BIN4	O Negative, Level	Comparator or Bin judgment result
19	/PARA-1 NG	/STEP-1 NG	/BIN5	O Negative, Level	Comparator or Bin judgment result
20	/PARA-2 NG	/STEP-2 NG	/BIN6	O Negative, Level	Comparator or Bin judgment result
21	/PARA-3 NG	/STEP-3 NG	/BIN7	O Negative, Level	Comparator or Bin judgment result
22	/PARA-4 NG	/STEP-4 NG	/BIN8	O Negative, Level	Comparator or Bin judgment result
23	--	--	/BIN9	O Negative, Level	Bin judgment result
24	--	--	/BIN out	O Negative, Level	Out of BINs

● **Handler I/O timing diagram:**

{ Connections to Handler Interface Board }



- NOTE:**
1. PIN1(trigger) + PIN5(GND) Start testing after short circuit, the shorting time must be greater than 100uS.
 2. The other output pins are photo coupler circuit, output signal is low level. The output is as a high resistance floating circuit when it without action.
 3. /EOM and /INDEX will be clean after the /TRIGGER executed.

3.4.4 Fixture Connecting

When connecting the fixture, it is required to discharge the power of Test Piece thoroughly. Turn the latches on both sides of the fixture to left until aligning with the small protruding point on the BNC port. Push the fixture down to the end and then rotate the latch rightward for fixing the fixture. Next, execute O/C and S/C trimming (See [7. Correction](#)) and load the measured Test Piece in-between both locking plates on the fixture. Then fasten the screws to secure the Test Piece and the measuring process can be started.



Insert the fixture FX-00C19



Turn the knob to the right



Press the open correction



Press the short correction



Measure the DUT


3.4.5 LAN Port

The instrument will be connected to the LAN (Local Area Network) ports. It can be selected as **Auto** or **Manual**. (Manual requires entering of network settings and IP configuration.)



Insert the RJ-45 cable to the LAN socket

Press Menu → System then press LAN setup



Auto



Manual

MAC ADDRESS:

LAN STATUS:

PORT:

CURRENT IP ADDRESS:

CURRENT SUBNET MASK:

CURRENT GETAWAY:

CURRENT DNS SERVER:

Sets the MAC address.

Displays the current network connection status.

Fixed as 111.

The IP address of the instrument.

Sets the network subnet mask.

Sets the gateway.

Sets the DNS.

3.4.6 Power Cord Connecting

Connect the power cord to the power jack of the instrument. Turn on the Power Switch, and the instrument is ready for use.



Figure 3.4.6.1 power jack




Figure 3.4.6.2 power key




Warning:

Before servicing the instrument, be sure to remove the power cord from the instrument. In addition, do not remove the plug when the hand is moistened as it may cause electrocution due to incorrect treatment. If the power cord or the power plug is damaged or loosened, it may cause the current leakage, burning, shorting or electrocution hazard.

Chapter 4 Basic Measuring

4.1 Meter Mode

Press “Menu” key and then select “Meter” Mode for accessing the Meter Mode page.



4.2 FREQ(Frequency)

The frequency range is 10Hz~50MHz, and the resolution is set at 6 digits. Press Input Digit key and then<Enter> to confirm the value or use the function key ↑↑↑, ↑↑, ↑, ↓, ↓↓, ↓↓↓ to adjust the frequency value by rough or minor adjusting method.

4.3 LEVEL

Select<Level> with<Direction> key. Press Input Digit key and then <Enter> to confirm the value for setting the signal level. The voltage range is 10mV~2Vrms, and the current range is 100 μA ~20mA_{rms}.

4.4 RANGE AC

Select<Range>with<Direction>key. It is preset as<Auto>. The measuring range belongs to internal parameter, which will be based to search the bay according to the measuring items. The range recommends setting as<Auto>in order to obtain better measuring accuracy. The range actually measured will be displayed at the lower-left corner of LCD panel. Further, there are also <1-30 Ω all frequency>, <2-300 Ω frequency below 1.2 MHz>, <3-3K Ω frequency below 120 KHz> and<4-30K Ω frequency below 12 KHz> ranges for option. Faster measuring speed can be achieved when setting at “Range Hold”.

4.5 SPEED

Select <SPEED> with <Direction> key. The <MAX.>, <FAST>, <MED.>, <SLOW> and <SLOW2> options are provided for the user to select according to their actual need.

4.6 BIAS

In setting the dc bias voltage, voltage range is $\pm 12\text{VDC}$, choose $\uparrow\uparrow, \uparrow, \downarrow, \downarrow\downarrow$,
Adjust it or click the number key (when input is above the instrument voltage range will be displayed outside range)

4.7 RANGE DC

Select <Range> with <Direction> key. It is preset as <Auto>. The measuring range belongs to internal parameter, which will be based to search the bay according to the measuring items. The range recommends setting as <Auto> in order to obtain better measuring accuracy. The range actually measured will be displayed at the lower-left corner of LCD panel. Further, there are also <1-30 Ω all frequency>, <2-300 Ω frequency below 1.2 MHz>, <3-3K Ω frequency below 120 KHz> and <4-30K Ω frequency below 12 KHz> ranges for option. Faster measuring speed can be achieved when setting at “Range Hold”.

4.8 TRIG

Use the <Up/Down> directional buttons to select. The options include <REPEAT> and <SINGLE>.

4.9 COMP

Use the <Up/Down> directional buttons to select. The options include <Compare category>.

4.10 Parameters

Press <Menu> key to select <Meter> mode and then move the cursor to the left side for setting the parameters to be measured.




Figure 4.10.1 Parameter

Parameters	Definition
RDC	DC Resistance
Ls	Equivalent Series Inductance
Lp	Equivalent Parallel Inductance
Cs	Equivalent Series Capacitance
Cp	Equivalent Parallel Capacitance
Q	Quality Factor, ($Q = 1/D$)
D	Dissipation Factor, Loss coefficient ($\tan\delta$)
Rs	Equivalent Series Resistance (ESR)
Rp	Equivalent Parallel Resistance
Z	Absolute value of impedance
θ_{deg}	Phase angle of impedance(degree)
θ_{rad}	Phase angle of impedance(radian)
R	Resistance
X	Reactance
Y	Absolute value of admittance
G	Conductivity
B	Susceptance
ϵ_r	Relative Permittivity, Dielectric constant
μ_r	Relative Permeability

NOTE:

When selecting parameter ϵ or μ , it is required to set ϵ_r and μ_r (see 4.10 SET ϵ_r and 4.11 SET μ_r)

4.11 MEASURER MODE SETUP

Press the **Setup** button on the instrument panel to enter the <MEASURE MODE SETUP> screen and perform measurement settings.



Figure 4.11.1 Setup button



Figure 4.11.2 Setup

4.11.1 TRIGGER DELAY

Set the trigger delay time, and such function is normally used by the automated equipment.

NOTE: The trigger delay time is set as 0-5000mS. If exceeding the high limit value, it will be adjusted back to 5000mS by the system automatically.

4.11.2 AC/DC DELAY

If AC parameter and RDC are included in the measuring, it can set the delay time between AC/DC measuring. This function is also suitable for when the measuring value of the Test Piece between AC/DC is instable.

4.11.3 AVERAGE

If the measuring value is instable, the average measuring count can be set within 1-64 times. The higher the average count, the steady the measuring value; on the contrary, the slower the measuring speed.

4.11.4 DISPLAY Vm/Im

It is preset as <No>. To display Vm/Im, then select <Yes> and the page will display the Vm/Im value of AC and DC. It recommends setting as <No> because it will affect the measuring speed.



Figure Vm/Im

4.11.5 BEEP WHEN

It is preset as <OFF>. The <FAIL> option means that the fail beep will sound if the test result is judged as <FAIL>. The <PASS> option means that the pass beep will sound if the test result is judged as <PASS>.

4.11.6 STATISTICS

The default value is <Off>. option <ON> displays the statistics, option <CLEAR> clears the current statistics and option <PRESET> restores default factory settings.

4.11.7 FONT SIZE

It is preset as <LARGE>. Select <LARGE> or <SMALL> to change the font of the page.



Figure Large / Small

4.12 TRIGGER MODE

Under the Meter Mode page, select <TRIG> with <Direction> key. It is preset as <REPEAT>, and the instrument will execute the measuring continuously. If selecting <SINGLE> option, then it must be activated by pressing <Trigger> key. The measuring will be repeated with each pressing of <Trigger> key.



Figure 4.12.1 Trig mode

4.13 LEVEL/RO/ALC

Under the Meter Mode page, select <LEVEL> with <Direction> key. Press Input Digit key and then <Enter> to confirm the value or use the function key \uparrow , \downarrow to adjust the Level value. The AC voltage range is 10mV~2Vrms, and the current range is 100μA~20mArms. The ADC voltage range is 10mV~1Vrms, and the current range is 400μA~40mArms



Figure 4.13 Level/Ro/ALC

4.13.1 RO (Output Impedance)

The <100Ω> or <25Ω> can be selected according to the user's demand. The varied signal source output impedance will lead to the varied current or the difference of measuring value. If selecting <25Ω>, then the AC voltage range change to 10mV~1Vrms, and the current range is 200μA~40mArms.

4.13.2 ALC (Auto Level Control)



Figure ALC

It is preset as <ALC OFF>. If selecting <ALC ON>, it ensures that the voltage applied to both ends of Test Piece or the current flowing through the Test Piece will be consistent with the parameter set value. If selecting <ALC ON>, because the instrument needs to calculate the voltage and the current for adjusting the output, it will increase the time required for the measuring. If the Auto Level Control cannot achieve the range to be set, the page will display <ALC unable to regulate> message, and it recommend setting as <ALC OFF> because it will affect the measuring speed.

4.14 SET ϵ_r

Selected <SETUP> function key then selected <SET ϵ_r > function key to access the <DIELECTRIC CONSTANT SETUP> page for setting up ϵ_r .



Figure Set ϵ_r



Figure Contacting and Non-contacting

Dielectric Coefficient Measurement Method

The <Contacting> or <Non-contacting> can be selected according to the tested material. If selecting the <Contact> measuring method, the user needs to set up the <DIAMETER> of polarity plate for the fixture and the <THICKNESS> of the tested material and <fixture correction coefficient>.

If selecting the <Non-contacting> measuring method, the user needs to set up the <THICKNESS> of the tested material as well as the <GAP> between the polarity plate of the fixture and the <EMPTY CAPACITACE> and <fixture correction coefficient>.

Fixture correction coefficient: This is the compensation parameter used for fixture Fx-0000c7 or Fx-000c20.

4.15 SET μ_r

Selected <SETUP> function key then selected <SET μ_r > function key to access the <PERMEABILITY SETUP> page.



Figure 4.15.1 Set μ_r

4.16 Magnetic Permeability Coefficient Measurement Method

For setting up the <HEIGHT>, <INNER DIAMETER> and <OUTER DIAMETER> of the tested material and <fixture correction coefficient>.

Fixture correction coefficient: This is the compensation parameter used for fixture Fx-0000C8.




Figure 4.16.1 Permeability setup

4.17 COMP (Comparison)


Under the Meter Mode page, select <COMP> with <Direction> key to access the comparison setup page. It is preset as “No”. When selecting “Yes”, the high/low limit range must be set for using as the measuring setup of the production line or the automated process.



Figure 4.17.1 Compare

4.17.1 COMPARATOR SETUP

Preset a reference value and upper and lower limit values as the comparative reference, and display a comparative result as green font (measured value is between UPPER and LOWER), red font (measured value exceed UPPER and LOWER).




Pass

Fail


4.17.2 COMP (Comparator) MODE & DISP (Display) Mode

- Value



Set the upper and lower limit values to identify the result.

- Δ



Enter reference values and then set absolute values corresponding to the reference values as the upper limit and lower limit values.

The measurement values displayed are displayed in deviations (Δ) from the reference value.

- $\Delta\%$

Upper limit value($\Delta\%$)	FAIL
Reference value(Ω)	Pass
lower limit value ($\Delta\%$)	Pass
	FAIL

Enter reference values and then set percentages corresponding to the reference values as the upper limit and lower limit values. The measurement values displayed are displayed in deviations ($\Delta\%$) from the reference value.

4.17.3 UPPER

The nominal value is used for executing the addition of Hi limit.

4.17.4 LOWER

The nominal value is used for executing the subtraction of Lo Limit. If selecting " Δ " or " $\Delta\%$ ", then the user needs to key in the negative mark before inputting the digits for the negative tolerance.


4.18 BIN SETUP

Select <Bin> for setting the bin conditions of each parameter, including Bin class 2~9. The Bin Method comprises sequence, error, random, equalization; whereas, the Value Mode comprises the Measuring Value, Tolerance value and Tolerance %.

<MEAS DISPLAY> FILE METER01				OFF
COMPARATOR/BIN SETUP				ON
PARAMETER	Ls	Rdc	Z	θd
COMP MODE	ABS	Δ ABS	$\Delta\%$	OFF
NOMINAL	500.00m Ω		1.4500 Ω	
UPPER	220.00 μ H	+5.0000m Ω	+2.0000 %	
LOWER	210.00 μ H	-5.0000m Ω	-2.0000 %	
DISP MODE	ABS	Δ ABS	$\Delta\%$	ABS
BIN	OFF	OFF	ON	OFF
FREQ	1.00000kHz	SPEED MED.	TRIG REPEAT	
LEVEL	1.000 Vac	LEVEL 1.000 Vdc	COMP ON	
RANGE	AUTO 30 Ω	RANGE AUTO 30 Ω		
RD 100R ALC OFF AVG OFF CORR On, OPEN, SHORT				SET BIN
				EXIT


4.18.1 PARAMETER and BIN NUMBER

Select the parameter and display up to 9 classifications of judgment results.




4.18.2 BIN METHOD

Equal: Set the upper and lower limit values for parameter, the Equal mode averages each the comparison values automatically. The Limit mode can select <ABS>, <△Abs> and <△%>.



Sequential: The Sequential mode specifies comparison limits as the absolute measurement value. The Limit mode can select <ABS>, <△Abs> and <△%>.



Tolerance: The tolerance mode specifies comparison limits by the deviation from the nominal value. The Limit mode can select <△Abs> and <△%>.

BIN SETUP	
PARAMETER	Z PARA 3
BIN NUMBER	3
BIN METHOD	Tolerance
LIMIT MODE	ΔABS
NOMINAL	1.4500 Ω
Bin 1	±50.000mΩ
Bin 2	±100.00mΩ
Bin 3	±150.00mΩ


Equal
Sequential
Tolerance
Random
EXIT

Random: Set the upper and lower limit values for each bin. The Limit mode can select <ABS>, <ΔAbs> and <Δ%>.

BIN SETUP	
PARAMETER	Z PARA 3
BIN NUMBER	3
BIN METHOD	Random
LIMIT MODE	ABS
	UPPER LOWER
Bin 1	1.5000 Ω 1.4000 Ω
Bin 2	1.6000 Ω 1.4000 Ω
Bin 3	1.7000 Ω 1.4000 Ω

Equal
Sequential
Tolerance
Random
EXIT

6632 uses three methods for specifying parameter limits as follows:



L_n : LOWER of BIN_n

U_n : UPPER of BIN_n

● : Includes the point

○ : Excludes the point

4.19 FILE

The parameter can be saved in the flash Memory of the instrument. The Meter Mode allows the user to access 100 setup groups, and the Multi-step List Test Mode allows the user to access 50 setup groups (with each group containing 15 measuring steps).




4.19.1 RECAL

After selecting the file to be opened with <Direction> key, click <Open> function key and you can enter the file.

4.19.2 NEW

Select <New> function key and the user can set up an empty file. After setting the file name, press <OK> and return to the Main Page for proceeding with the parameter setup.



4.19.3 SAVE AS

After setting the parameter, select <Save As> function key and set the file name. Next, press <OK> and the parameter setup can be saved in the new file.

4.19.4 DELETE

Select <DELETE> function key to delete the file, the file which is being used cannot delete.

4.19.5 USB FILE

Insert the USB flash drive into the USB port on the front panel of the instrument, select<USB FILE> function key to access the USB IA6632 folder.

4.19.6 COPY>USB

Insert the USB flash drive into the USB port on the front panel of the instrument, select<COPY>USB> to copy 6632 local file to USB flash drive.

- | |
|--|
| <p><u>NOTE:</u></p> <ol style="list-style-type: none">1. The METER mode setting file is saved to USB flash drive root IA6632-->METER.2. The Multi-steps mode setting file is saved to USB flash drive root IA6632-->LIST.3. It can only use <SAVE SCREEN>to save the METER mode and the Multi-steps mode's test result as BMP (graphics) file, the .bmp file is saved to USB flash drive root IA6632-->SCREEN.4. The SWEEP mode measurement data and screen graphics is save to USB flash drive root-->SWEEP |
|--|

Chapter 5 LIST TEST

Press <Menu> key and select <LIST SET> for executing the multi-step setup. The measurement frequency or measurement signal level differs for each panel allows you to simply evaluate the characteristics of the DUT. Such function can be used in the production line or the automation test and, at most, 15 testing steps can be set.

<LIST SET>	FILE	LIST01	BIN	OFF	FILE
STEP	1	2	3		
PARAMETER	Off	Off	Off		
FREQUENCY					
LEVEL					
DC BIAS					
SPEED					
DELAY					
COMP MODE					
NOMINAL					LIST RUN
UPPER					
LOWER					


5.1 LIST SET

Select <LIST SET> function key. Press left/right <Direction> key to select Step 1~15 STEP, and press up/down <Direction> key to select PARAMETER, FREQUENCY, LEVEL, DC BIAS ,SPEED, DELAY, COMP MODE, NOMINAL, UPPER and LOWER. After being set, select <List Run> key to access multi-step testing page.

<LIST SET>	FILE	LIST01	BIN	OFF	FILE
STEP	1	2	3		
PARAMETER	Ls	Z	Q		
FREQUENCY	1.00000kHz	1.00000kHz	1.00000kHz		
LEVEL	1.000 V	1.000 V	1.000 V		
DC BIAS	+0.000 V	+0.000 V	+0.000 V		
SPEED	MED.	MED.	MED.		
DELAY	0mS	0mS	0mS		
COMP MODE	VALUE	VALUE	VALUE		
NOMINAL					LIST RUN
UPPER	10.000mH	65.000 Ω	8.0000		
LOWER	9.5000mH	60.000 Ω	7.0000		

5.2 LIST MODE SETUP

Under the <LIST SET> or <LIST RUN> page, selected <SETUP> function key and you can access the <LIST MODE SETUP> page for executing the measuring setup.



5.2.1 TRIGGER MODE

It <REPEAT><SINGLE><AUTO> three different types of trigger can be set. Selecting <REPEAT> option, the instrument will execute the measuring continuously. Selecting <SINGLE> option, it must be activated by pressing <Trigger> key (signal), the measuring will be repeated with each pressing of <Trigger> key (signal). Selecting <AUTO> option, the measuring will start automatically, when the DUT measuring circuit connects incorrect.

5.2.2 TRIGGER DELAY

Set the trigger delay time, and such function is normally used by the automated equipment.

NOTE:

The trigger delay time is set as 0-5000mS. If exceeding the high limit value, it will be adjusted back to 5000mS by the system automatically.

5.2.3 Automatic trigger determination point mode

Sets the trigger mode as automatic detection; the automatic trigger determination can be set from 0.01uA ~ 20000.00uA as the trigger determination point.

When the value is greater than the determination point, it means that the DUT has been connected; when the value is less than the determination point, it means that the DUT has been disconnected.

5.2.4 OUTPUT IMPEDANCE

The <100Ω> or <25Ω> can be selected according to the user's demand. The varied signal source output impedance will lead to the varied current or the difference of measuring value. If selecting <25Ω>, then the AC voltage range change to 10mV~1Vrms, and the current range is 400μA~40mA_{rms}.

5.2.5 ALC

It is preset as <ALC OFF>. If selecting <ALC ON>, it ensures that the voltage applied to both ends of Test Piece or the current flowing through the Test Piece will be consistent with the parameter set value. If selecting <ALC ON>, because the instrument needs to calculate the voltage and the current for adjusting the output, it will increase the time required for the measuring. If the Auto Level Control cannot achieve the range to be set, the page will display <ALC FAIL> at the lower-right corner of panel, and it recommend setting as <ALC OFF> because it will affect the measuring speed.

5.2.6 BEEP WHEN

It is preset as <OFF>. The <FAIL> option means that the fail beep will sound if the test result is judged as <FAIL>. The <PASS> option means that the pass beep will sound if the test result is judged as <PASS>.

5.2.7 RANGE HOLD

It is preset as <ON>. If selecting <ON>, the measuring range is hold at the range, which is used by the first time measuring. If selecting <OFF>, the most suitable test range is set automatically. Faster measuring speed can be achieved when setting at <ON>.

5.2.8 FAIL RESET

It is preset as <OFF>. It retest continuously until the test result is pass, when the test result is fail. If selecting <OFF>, it doesn't execute this function. If selecting <STEP 1>, only the first step is going to retest. If selecting <ALL>, no matter which step occur fail result, the fail step is going to retest until the result become pass.

5.2.9 STATISTICS

Whether to enable the result statistics function located at the bottom-right corner; <Clear> will reset all PASS and FAIL statistics and continuing keeping statistics all over again.

5.2.10 TERMINATED AT NG STEP

When TERMINATED AT NG STEP is set as <ON>, the test will be terminated when any NG is detected during testing.

5.2.11 PRESET


It resets the LIST file as a new List file, all of the steps are deleted.
<TRIGGER MODE: SINGLE>;<TRIGGERDELAY:0mS>,
<OUTPUTIMPEDANCE:100>, <ALC:OFF>, <BEEPWHEN:OFF>,
<RANGEHOLD:ON>, <FAILRETEST:OFF>,
<STATISTICS:OFF>.

5.3 CORR.(LIST CORRECTION)

Under the LIST SET or LIST RUN page, list correction and meter correction are not the synchronize function. It suggests doing List Correction when starting multi-step testing at the first time or changing any List setup value.


Chapter 6 SWEEP

Press<Menu> key and select <Sweep> Mode for entering the Sweep Mode page. The Sweep Mode displays the component characteristics by visual method and the user can select voltage, current and frequency sweeping for using as the horizontal coordinates. If the sweeping result exceeds the vertical range, then the instrument will adjust the scale automatically; further, more suitable measuring can be achieved with the use of the cursor.



6.1 SWEEP MODE SETUP

Under the Sweep mode page, select <SETUP> function key for accessing the SWEEP MODE SETUP page.




6.1.1 SWEEP DELAY

The delay time between each sweeping point can be set according to the user's need. When set at Sweep Delay Mode, it will affect the entire measuring time.


NOTE:

The trigger delay time is set as 0-5000mS. If exceeding the high limit value, it will be adjusted back to 5000mS by the system automatically.



6.1.2 OUTPUT IMPEDANCE


The<100Ω>or<25Ω> can be selected according to the user's demand. The varied signal source output impedance will lead to the varied current or the difference of measuring value. If selecting <25Ω>, then the AC voltage range change to 10mV~1Vrms, and the current range is 400μA~40mArms.



6.1.3 KEEP PREVIOUS TRACE

When <KEEP PREVIOUS TRACE> is selected <ON>, the graph drawn for the last sweeping remains and is overwritten with a brighter graph for the most recent measurement results.

When <KEEP PREVIOUS TRACE> is selected <OFF>, the graph drawn for the last measurement is deleted and a graph for the most recent sweeping results is drawn.



6.1.4 TRACE A/B COLOR

Use the <COLOR -> and <COLOR +>function key to set the color of trace A/B.




6.1.5 PRESET

It resets the Sweep mode setup. <TYPE-FREQUENCY>; <XAXIS-LOG>; <START-20Hz>; <STOP-3/5/10/20/30MHz>; <LEVEL-1V>; <TRIG-SINGLE>; <SPEED-FAST>; <SCALE-TRACE A>; <FUNC-Z-DEG>; <SWEEP DELAY-0mS>; <OUTPUT IMPENANCE-100Ω>; <KEEP PREVIOUS TRACE-OFF>; <TRACE A COLOR-yellow>; <TRACE B COLOR-green>.

6.1.6 CURSOR

The <CURSOR> function can easily find the maximum value, minimum value, and self-resonant frequency parallel/serial, then the searching result will be displayed at the lower-middle of LCD panel.

<TrA MAX: traceA's maximum value>, <TrA MIN: traceA's minimum value>, <TrB MAX: traceB's maximum value>, <TrB MIN: traceB's minimum value>, <SRF fs: self-resonant frequency serial>, <SRF fp: self-resonant frequency parallel>




6.1.7 AUTO FIT

If the sweeping result exceeds the vertical range, then press <AUTO FIT> key to adjust the sweeping graph automatically.


6.1.8 TYPE

It is preset as <FREQUENCY>. Use <Direction> key and the user can switch to <VAC: Voltage> or <IAC: Current>.



6.1.9 X-AXIS

The <X-AXIS> can be set as <LINEAR> or <LOG>. The Linear Mode is divided into 250 equal portions with starting and ending values, and the Log Mode changes along with the set value.



6.1.10 START/STOP

<START>Use the numeric keypad to set the starting value of the sweep.

<STOP>Use the numeric keypad to set the ending value of the sweep.


6.1.11 LEVEL

Under the frequency sweep type, it can set the measurement voltage or measurement current.

Under the voltage/current sweep type, it can set the measurement frequency.


6.1.12 TRIG

It <REPEAT><SINGLE> two different types of trigger can be set. Selecting <REPEAT> option, sweeping can be repeated unlimited time after you press <Trigger> key (signal). Selecting <SINGLE> option, it must be activated by pressing <Trigger> key (signal), the sweeping will be repeated with each pressing of <Trigger> key (signal).




6.1.13 SPEED

The sweep speed is available in “Fast”, “Medium” and “Slow” for option.




6.1.14 FUNC

It can select default common parameter sets.




6.1.15 TRACE A/B PARA

It sets the parameters to be analyzed




6.1.16 TRACE A/B Y-AXIS

The Y-AXIS can be set as “Linear” or “Log.”



6.1.17 TRACE A/B REF

When <Y-AXIS> is selected <LINEAR> type, it can change values of the reference line by using numeric keypad.



6.1.18 TRACE A/B POS

Moving trace A/B up or down by using <move↑> and <move↓>.




6.1.19 TRACE A/B DIV/DECADE

Adjusting trace A/B's amplitude size by using <ZOOM-> and <ZOOM+>.


When <LINEAR> type is selected at Y-AXIS, <DIV> is set.


When <LOG> type is selected at Y-AXIS, <DECADE> is set.











6.2 Equivalent Circuit Analysis (option)







The equivalent circuit analysis function estimates equivalent circuit constants based on measurement results. The 6632 can estimate 3-element model and 4-element model. By using the simulation function, you can display frequency characteristic ideal values using estimation results or user-configured constants.





Use <mode-> and <mode+> function key to set the equivalent circuit type. Move the cursor to the equivalent circuit values; you can enter the desired value with numeric keypad or use <↑↑>, <↑>, <↓> and <↓↓> to do the fine adjustment, then you can simulate the equivalent circuit.

Equivalent Circuit Model		Typical Frequency Characteristics	DUT Example
A			Inductor: Inductor with high core loss and low ESR
B			Inductor: Inductor with comparatively high ESR Resistor: Resistor with low resistance value and significant wiring inductance effect
C			Capacitor: Capacitor with significant leak resistance effect Resistor: Resistor with high resistance value and significant stray capacitance effect
D			Capacitor: Typical capacitor

E			Piezoelectric element Resonator
F			Inductor with high ESR
G			Capacitor with high ESR


*Typical frequency characteristics graphs


For models A, B, C, D, F and G, the horizontal axis is logarithmic, the vertical axis (Z) is logarithmic, and θ is linear.

For model E, the horizontal axis is linear or logarithmic, the vertical axis (Z) is logarithmic and θ is linear.

Chapter 7 CORRECTION


Press the <Menu> key and select <CORR.> function key for accessing the CORRECTION page. Before each measuring, the user needs to calibrate (balance) the fixture or the test cable in order to eliminate the stray capacitance and the series impedance that may be produced by the fixture or the test cable. It is especially suitable for the application when using the machine in a new environment or using (replacing) new fixture. For details of fixture connection method, please refer to 3.4.4 Fixture Connecting.






7.1 Open Circuit Correction

In CORRECTION page, use <OFF><ON> function key to open the open circuit correction, and use <Open> function key to do the open circuit correction. Before starting the open circuit correction, do not load the Test Piece to avoid correction failure. If the correction fails or the figure is incorrect, the page will display the correction failure message; if successful, it will return to the CORRECTION page automatically.



Test Cable Open Circuit Correction Method



Fixture Open Circuit Correction Method (be sure to lock the reed tightly)


NOTE:

The open circuit correction is quite sensitive to noise - both noise originating externally and induced noise. Therefore, if open circuit correction fails, you should check the following points before starting the correction process again:


	<ul style="list-style-type: none"> ● Check that the test fixture or the test cables are properly connected. ● Check that nothing is connected to the test fixture or the test cables. (Open circuit correction cannot be performed while any test piece is connected to the test fixture or the test cables.) ● Check the test leads are arranged as closely as possible to their configuration in which measurement will be performed. ● During the correction process, be sure not to disturb the fixture and the test cables or to move your hand near them.
--	---

7.2 Short Circuit Correction

In CORRECTION page, <OFF><ON> function key to open the short circuit correction, and use <Short> function key to do the short circuit correction. Before starting the short circuit correction, please insert the shorting plate into the fixture for executing the short circuit correction. If the correction fails or the figure is incorrect, the page will display the calibration failure message; if successful, it will return to the CORRECTION page automatically.



Test Cable Short Circuit Method



Fixture Short Circuit Method (lock the reed tightly after inserting the shorting bar)

<u>NOTE:</u>	If short circuit correction fails, you should check the following points before starting the correction process again:
---------------------	--

	<ul style="list-style-type: none"> ● Check that the test fixture or the test cables are properly connected. ● Check that the test fixture or the test cables are properly shorted together with the shorting bar. (Short circuit correction cannot be performed while any test piece is connected to the test fixture or the test cables.) ● Check the test leads are arranged as closely as possible to their configuration in which measurement will be performed. ● During the correction process, be sure not to disturb the fixture and the test cables or to move your hand near them.
--	--

7.3 HF LOAD

When the measured frequency exceeded 1MHZ, execution of high frequency load correction is recommended.

Connect the FX-000C19 fixture to the instrument, place the STD-LOAD high frequency correction disk and clamp it tightly in place, and then press high frequency correction.


7.4 SPOT LOAD

The fixed frequency point, frequency, load correction parameter and standard reference value can only be set when fixed frequency load correction is set as <ON>.



7.5 CABLE LENGTH

Choose the length of the testing wire. There are 0, 0.5, 1, and 2 meters. Four types of length can be chosen.




7.6 FIXTURE COMPENSATION

Choose the fixture model. There are <F42001>, <FX-000C20>, <FX-000C19>, <FX-000C12>, <FX-000C10>, <FX-000C8>, <FX-000C7>, and <FX-000C6>.




7.7 Spot. No.

Set the fixed frequency point; the range is from 1~16.




7.8 FREQUENNCY

Choose the frequency value



7.9 LOAD FUNCTION

Click the \uparrow / \downarrow swap the primary and secondary parameters.
 (EX:<G-B>、<R-X>、<CP-RP>、<CP-D>、<CS-RS>、<CS-D>、<LP-RP>、<LP-Q>、<LS-RS>、<LS-Q>、<Y-Deg>、<Z-Deg>。





7.10 Reference

Insert the known values with measurements as reference values




7.11 Load

It is the value that is measured in the beginning to correct the result value.



Chapter 8 SYSTEM CONFIG

Press <Menu> key and then select <SYSTEM> mode for accessing the SYSTEM CONFIG page. The 6632 Precision Impedance Analyzer supports 3 language interfaces, <English>, <Traditional Chinese> and <Simplified Chinese>. The language can be preset with the function key.



NOTE:

The “Specific Term” or “Font” factors must still be expressed in “English”.

8.1 LANGUAGE

Under SYSTEM CONFIG page, select <LANGUAGE> and use <English>, <Traditional Chinese> and <Simplified Chinese> function key to set the language interface.

8.2 GPIB ADDRESS

Under SYSTEM CONFIG page, select <GPIB ADDRESS> and set the GPIB Address within the range of 1~30 with the numeric keypad.

8.3 RS232 BAUD RATE

Under SYSTEM CONFIG page, select <RS232 BAUD RATE> and use <14400>, <19200>, <38400>, <56000> and <115200> function key to set the RS232 Baud Rate.

8.4 RS232 EOI

Under SYSTEM CONFIG page, select <RS232 EOI> and use <LF>, <CR> and <LF+CR> function key to set the RS232 End of Identify.

8.5 LAN PORT

Selecting <LAN PORT> from the system setting screen also allows selecting of ON or OFF. The LAN setting may be set as manual or automatic, allowing users to control the instrument using LAN functions.

8.6 HANDLERINTERFACE

Under SYSTEM CONFIG page, select <HANDLER INTERFACE>, use <ON><OFF> function key and open the remote I/O control program for the user to monitor the signal input and PASS/FAIL output result by controlling the instrument remotely.

8.7 KEY BEEP


Under SYSTEM CONFIG page, select <KEY BEEP> and use <ON><OFF> function key to set the beep sound when key pressed.

8.8 BIAS Resource

Under SYSTEM CONFIG page, select <BIAS>, choose your setting, NO, 12V, 40/100mA, 622X/4X.



No:

1. Select “NO” for Rdc measurement. ◦



12V :

1. “Connect Status” will show “connected” or “disconnected” while choosing 12V.
2. Build-in DC Bias voltage setting range is $\pm 12\text{Vdc}$.
3. Enter meter mode and set 4 display parameters and set Bias voltage. .
4. Press “Bias” to output bias voltage.
5. Test will not start when Rdc is one of the parameters on the display. It shows “9999.99MΩ” (Please select ”NO” for bias source)



6220/6240:

1. With single or multiple 6220/40, it is DC Bias Test system.
2. Option items are 6210/ 6220/ 6223/ 6225/ 6240/ 6243
3. 6632 Lcur 、Lpot 、Hpot 、Hcur with 62xx Lcur 、Lpot 、Hpot 、Hcur . (option)
4. Multiple DC Bias source included standard accessories black and red current board to connect each other. (Figure 8.8.1)
5. 62xx other side Lcur 、Lpot 、Hpot 、Hcur connect F6210 fixture(standard accessory) .
6. Insert power line and internet cable to EXT.I/O.
7. Switch the number for each instrument according to the order from 1 to X.




Figure 8.8.1

8. Press “DETAIL” to enter multiple instrument status. (Figure 8.8.2)



Figure 8.8.2 Bias source

9. Press “Menu” key to enter meter mode and set the conditions and parameters such as current, frequency, etc. (About Rdc, you should turn on the bias and then you can measure the Rdc.)
10. Press “BIAS” to trigger the measurement.
11. Press “MENU” to show the list on the right side and select “TEMP” to enter temperature rise page.



Figure 8.8.3 TEMP

12. We recommend do the short correction in the temperature rise function.
13. Insert the fixture with correction chip and clamp it. Press “SHORT” to initiate the correction.
14. Remove the chip. Insert your DUT and set BIAS, time, alarm at, and stop at. Press “BIAS” to send the current, and press “Trigger” to start the test.
15. Current: 0A~320A , depends on the quantity of your instrument.
16. Time: 0 to 60 sec.
17. Alarm at: 0~200 degree. Instrument beep when it reaches the setting temperature.
18. Stop at: 0~200 degree. The test stops at setting temperature.




Figure 8.8.4 Temp page and short

19. Press “ISAT” and set BIAS, level, freq. and speed. Press” BIAS” to output current and press “Trigger “to start the test.
 - Current: 0A~320A, depends on your instrument type
 - Freq.: 10Hz~50Mhz (depends on your instrument type)
 - Level: 0.40mAac ~ 40mAac 、 0.010Vac ~ 1.000 Vac
 - Speed: Max., Fast, Med., SLOW, SLOW2.
 - +-% : -90%~0% 或 10%~100% 。




Figure 8.8.5 ISAT page

※ All models for DC bias current

Model	Amp	Max unit	Max Amp	Resonance frequency
6210	10A	6	60A	100Hz to 3MHz
6220	20A	6	120A	
6223	20A	6	120A	
6240	40A	8	320A	100Hz to 1MHz
6243	40A	8	320A	100Hz to 10MHz
6225	20A	1	20A	100Hz to 30MHz

Chapter 9 Appendix

9.1 |Z| Accuracy Chart



9.2 Measurement accuracy

Conditions of accuracy

All specifications apply at 23 ± 5 °C, and 60 minutes after the instrument has been turned on.

Impedance measurement accuracy at 4-terminal test fixture (Typical at > 10 MHz)

[Z], [Y] accuracy	$\pm Ae$ [%], Where Relative accuracy $Ae = (Ab + Az + Av + Ad + Ac) \times Kt$ [%]	
θ accuracy	$\pm Ae/100$ [rad]	
L, C, X, B accuracy		
at $Dx \leq 0.1$	$\pm Ae$ [%]	
at $Dx > 0.1$	$\pm Ae \times \sqrt{1 + Dx^2}$ [%]	
R accuracy		
at $Dx \geq 10$ ($Qx \leq 0.1$)	$\pm Ae$ [%]	
at $0.1 < Dx < 10$ ($10 > Qx > 0.1$)	Rs: $\pm Ae \times \sqrt{1 + Dx^2}/Dx$ [%], Rp: $\pm Ae \times \sqrt{1 + Dx^2}/(Dx \mp \frac{Ae}{100} \times \sqrt{1 + Dx^2})$ [%]	
at $Dx \leq 0.1$ ($Qx \geq 10$)	Rs: $\pm Ae / Dx$ [%], Rp: $\pm Ae / (Dx \mp Ae/100)$ [%]	
G accuracy		
at $Dx > 0.1$	$\pm Ae \times \sqrt{1 + Dx^2}/Dx$ [%]	
at $Dx \leq 0.1$	$\pm Ae/Dx$ [%]	
D accuracy		
at $Dx \leq 0.1$	$\pm Ae/100$	
at $0.1 < Dx \leq 1$	$\pm Ae \times (1 + Dx)/100$	
Q accuracy (at $Qx \times Da < 1$)		
at $Qx > 10$, ($Dx < 0.1$)	$\pm (Qx^2 \times Ae / 100) / (1 \mp Qx \times Ae/100)$	
at $Qx \leq 10$, ($Dx \geq 0.1$)	$\pm (Qx^2 \times Ae(1 + Dx)/100) / (1 \mp Qx \times Ae(1 + Dx)/100)$	

NOTE: Da: measurement accuracy of D, Dx : measurement value of D, Qx : measurement value of Q


$$Ae = (Ab + Az + Av + Ad + Ac) \times Kt \quad [\%]$$

Ab [%]	Frequency: F[Hz], Fm[MHz]	
	F < 200Hz	$0.08 + (200 / F - 1) \times 0.0222$
	200Hz \leq F \leq 500kHz	0.08
	F > 500KHz	$0.08 + (Fm - 0.5) \times 0.0472$
Az [%]	Impedance Range [Ω]	
	$Zx \leq 100\Omega$:	$(100/Zx - 1) \times 0.001 \times Km$
	F < 100Hz:	$Km = 1 + (100/F - 1) \times 0.112$
	100Hz \leq F \leq 1MHz:	$Km = 1$
	F > 1MHz:	$Km = 1 + (Fm - 1) \times 3$
	$Zx > 100\Omega$	$(Zx/100 - 1) \times 0.00001 \times Kn \times Kp$
	F < 100Hz	$Kn = 1 + (100/F - 1) \times 0.112$
	100Hz \leq F \leq 50KHz	$Kn = 1$
	F > 50KHz	$Kn = F/50K$
	F \leq 1MHz	$Kp = 1$
	F > 1MHz	$Kp = 1 + (Fm - 1) \times 0.5$
Av [%]	Signal Level [V]	
	Vac > 0.5V: $(Vac - 0.5)^2 \times 0.45 \times (1 + Fm/30)$	
	Vac \leq 0.5V: $(0.5/Vac - 1) \times 0.25$	
Ad [%]	Measurement Speed	
	(5) SLOW2 :	0
	(4) SLOW :	0
	(3) MED :	0.1
	(2) FAST :	0.2
	(1) MAX :	0.4
Ac [%]	Cable length [m]	
	0 m:	0 Fm: 0 to 50 [MHz]
	0.5 m:	$0.02 + 0.01 \times Fm$ Fm: 0 to 20 [MHz]
	1 m:	$0.02 + 0.02 \times Fm$ Fm: 0 to 10 [MHz]
	2 m:	$0.02 + 0.03 \times Fm$ Fm: 0 to 5 [MHz]

Kt	Temperature [°C]
	8 - 18°C: 4
	18 - 28°C: $1 + (T - 23)^2 \times 0.0139$
	28 - 38°C: 4

Measurement Time / Averaging

Measurement Speed	1.Max:	2.5ms (>10kHz)
	2.Fast:	50ms (>20Hz)
	3.Medium:	100ms
	4.Slow:	300ms
	5.Slow2:	600ms
Display Time	1.6 ~ 5.6ms (depend on the contents)	
Averaging Range	1 to 64	



Chapter 10 Concept of Command


◆ Subsystem Command Tree

The top of the subsystem command tree is called the root command, or simply the root. To reach the low-level commands, you must specify a particular path. After Power ON or after *RST, the current path is set to the root. The path settings are change as follows:

Colon (:) When a colon is placed between two command mnemonics, the colon moves the current path down one level on the command tree. When the colon is the first character of a command, it specifies that the following command mnemonics are a root-level command.

Semicolon (;) A semicolon separates two commands in the same message without changing the current path.

Proper use of the Colon and Semicolon as follows:



1. ^R:^DAA:CC

R) Sets current path to ROOT

2. ^R:^DAA:^DBB:^NEE;^NFF;GG

N) No change to current path

3. ^R:^DAA:^DDD:^NHH;JJ

D) Set current path DOWN one level

4. ^R:^DAA:^DBB:^NEE;^R:^DAA:^DDD:^NHH

It shows how character input time can be saved by properly using semicolons. Sending the message

:AA:BB:EE;FF;GG

is equivalent to sending the following three messages.

:AA:BB:EE

:AA:BB:FF

:AA:BB:GG

◆ Data Format

`:MEASure:PARAMeter<NR1> LF`

1. Command
2. Space
3. Parameter
4. Program Message Terminator

Parameter:

There must be a <space> between the last command and the first parameter in a subsystem command.

For example: `:MEASure:PARAMeter Z`

If you send more than one parameter with a single command, each parameter must be separated by a comma.

For example: `:MEASure:PARAMeter Z,LS,Q`

<> Angular brackets enclose words or characters that are used to symbolize a program code parameter or a command.


<NR1>Integers	Example: 1,2,3,4
<NR2> Decimal number	Example: 0.1,0.23,0.001
<NR3> Float	Example: 2.2E+2,1.1E-1
<disc> Discrete data	Example:

ON,OFF,MAXimum,MINimum

{ } When several items are enclosed by braces, one and only one of these elements may be selected. A vertical bar can be read as "or" and is used to separate alternative parameter options.

For	example:
<code>:MEASure:SPEED{MAXimum FAST MEDIUM SLOW SLOW2}</code>	
Means	<code>:MEASure:SPEED MAXimum</code> or <code>:MEASure:SPEED FAST..... °</code>

◆ Common Commands



<Command> :STATus:OPERation:CONDition?

Function:It queries the status of Operation Status Register.

Description:

Return data 0~65535 (Format is in <NR1>)

<Command> :STATus:OPERation:EVENT?

Function:It queries the status of Operation Event Register.

Description:

Query syntax: STATus:OPERation:EVENT?

Return data 0~65535 (Format is in <NR1>)

<Command> :STATus:OPERation:ENABLE <NR1>

:STATus:OPERation:ENABLE?

Function:It sets or queries the status of Operation Enable Register.

Description:

Set parameter 0~65535 <NR1>

Set syntax:STATus:OPERation:ENABLE 65535

Query syntax:STATus:OPERation:ENABLE?

Return data 65535 (Format is in <NR3>)

<Command> :STATus:QUEStionable:CONDition?

Function:It queries the status of Questionable Condition Register.

Description:

Query syntax:STATus:QUEStionable:CONDition?

Return data 0~65535 (Format is in <NR1>)

<Command> :STATus:QUEStionable:EVENT?

Function:It queries the status of Questionable Event Register.

Description:

Query syntax: STATus:QUEStionable:EVENT?

Return data 0~65535 (Format is in <NR1>)

<Command> :STATus:QUEStionable:ENABLE <NR1>

:STATus:QUEStionable:ENABLE?

Function:It sets or queries the status Questionable Enable Register.

Description:

Set parameter 0~65535 <NR1>

Set syntax:STATus:QUEStionable:ENABLE 65535

Query syntax:STATus:QUEStionable:ENABLE?

Return data 0~65535 (Format is in <NR1>)

<Command> *CLS

Function:It clears Error Queue, Standard Event Status Register, Status Byte Register, and Operation Event Register.

<Command> *ESE <NR1>

*ESE?

Function:It sets or queries the status of Standard Event Status Enable Register.

Description:

Set parameter 0~255

Set syntax*ESE 1

Query syntax*ESE?

Return data 1 (Format is in <NR1>)

<Command> *ESR?

Function:It queries the status of Standard Event Status Register, clean the Register after executed.

Description:

Query syntax*ESR?

Return data<NR1>

<Command> *IDN?

Function:It queries the device basic data.

Description:

Return dataMICROTEST,6632-30G,0,1.194<field1>,<field2>,<field3>,<field4>

<field1>manufacturer

<field2>model number

<field3>serial number or 0

<field4>firmware revision

MICROTEST,6632-30G,0,1.194

<Command> *OPC

Function:It sets Standard Event Status Register to 0 bit,when all operations are completed.

<Command> *OPC?

Function:When all operations are completed, 1 will be returned.

Query syntax*OPC?

Return data 1

<Command> *OPT?

Function:It queries the installed in the system interface.

Description:

Query syntax*OPT?

Return data If 6632 MAX test frequency is 1MHz , it returnsF01
If 6632 MAX test frequency is 3MHz, it returns F03
If 6632 MAX test frequency is 5MHz, it returns F05
If 6632 MAX test frequency is 10MHz, it returns F10
If 6632 MAX test frequency is 15MHz, it returns F15
If 6632 MAX test frequency is 20MHz, it returns F20
If 6632 MAX test frequency is 30MHz, it returns F30
If 6632 MAX test frequency is 50MHz, it returns F50

<Command> *RST

Function:It aborts all pending operations, and sets 6632 to its initial setups.

Description:

Initial Setups

Parameters:Ls,Q,Z,θdeg

FREQuency:1kHz

LEVEL:1Vac

SPEED:MED.

TRIGger:REPEAT

<Command> *SRE <NR1>

*SRE?

Function:It sets or queries the status of Service Request Enable Register.**Description:**

Set parameter 0~255

Set syntax*SRE 1

Query syntax*SRE?

Return data 1 (Format is in <NR1>)

<Command> *STB?**Function:**It queries the status of Service Request Status Register**Description:**

Query syntax*STB?

Return data<NR1>

<Command> *WAI**Function:**It makes 6632 waits until all previously sent commands are completed. The 6632 then continues executing the commands that follow the *WAI.**<Command>** *TST?**Function:**The response to this query is always 0.

Query syntax *TST?

Return data 0

<Command> *TRG

*TRG?

:TRIGger

:TRIGger?

Function:.It executes Trigger action. If using *TRG? and :TRIGger, it executes Trigger action and returns test data.

Set syntax*TRG

Query syntax*TRG?

Return data -6.337855E-08,+3.980846E-06,+1.000338E+02,-2.280857E-04,0

<Command> :DISPlay:PAGE

{MEASure|SWEep|CORRection|LSET|LRUN|LCORRection|SYSTem}

:DISPlay:PAGE?

Function:It sets or queries the page currently displayed on the LCD screen.**Description:**

Set parameter MEASure(meter mode), SWEEp(sweep mode), CORRection(correction page),
LSET(list mode), LRUN(list run), LCORection (list correction page), SYSTem(system page).
Set syntax :DISPlay:PAGE MEASure
Query syntax :DISPlay:PAGE?
Return data MEAS (Format is in <disc>)

◆ MEASure Subsystem

<Command> :MEASure:PARAMeter
{OFF|RDC|LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B|E|U}
:MEASure:PARAMeter?

Function: It sets or queries the measurement parameter (max.4 items) at present.

Description:

Set parameter OFF, RDC(DC Resistance), Ls(Series Inductance), Lp(Parallel Inductance), Cs (Series Capacitance), Cp (Parallel Capacitance), Q (Quality Factor), D (Dissipation Factor), Rs (Series Resistance) Rp(Parallel Resistance), Z(Impedance), θ_d (Angle), θ_r (Diameter), R(Resistance), X(Reactance), Y (Admittance), G (Conductivity), B (Susceptance), E(Relative Permittivity), U(Relative permeability)

Set syntax:MEASure:PARAMeter RDC,Z,DEG,OFF

RDC is the first measure parameter, the second is Z, the third is θ_{deg} and the forth is OFF.

Query syntax:MEASure:PARAMeter?

Return dataRDC,Z,DEG,OFF

<Command> :MEASure:FREQuency<frequencyNR3/disc>
:MEASure:FREQuency?

Function: It sets or queries the FREQUENCY.

Description:

Set parameterThe setup value of frequency is
{10.0~30000000.0|MAXimum|MINimum}.

Set syntax :MEASure:FREQuency 1000
:MEASure:FREQuency1K
:MEASure:FREQuency 1KHZ
:MEASure:FREQuency 1E3
:MEASure:FREQuency MAXimum
:MEASure:FREQuency MINimum

Query syntax:MEASure:FREQuency?

Return data 1.000000E+03 (Format is in <NR3>)

<Command> :MEASure:SPEED
{MAXimum|FAST|MEDIUM|SLOW|SLOW2|0|1|2|3|4}
:MEASure:SPEED?

Function: It sets or queries the SPEED.

Description:

Set parameter MAXimum/0, FAST/1, MEDIUM/2, SLOW/3, SLOW2/4

Set syntax:MEASure:SPEED 1
:MEASure:SPEED FAST

Query syntax:MEASure:SPEED?

Return data FAST (Format is in <disc>)

<Command> :MEASure:BEEPer {OFF|PASS|OK|FAIL|NG|0|1|2}
:MEASure:BEEPer?

Function:It sets or queries the BEEP WHEN.

Description:

Set parameter OFF, PASS|OK, FAIL|NG

Set syntax: MEASure:BEEPer PASS
:MEASure:BEEPer NG
:MEASure:BEEPer OFF

Query syntax: MEASure:BEEPer?

Return data PASS| FAIL| OFF

<Command> :MEASure:VOLTage:AC <voltage NR3/disc>
:MEASure:VOLTage:AC?

Function:It sets or queries the AC measurement voltage (LEVEL).

Description:

Set parameter When RO(output impedance) is setting 100Ω , the setup value of AC voltage is {0.01~2|MAXimum|MINimum}. When RO(output impedance) is setting 25Ω , the setup value of AC voltage is {0.01~1|MAXimum|MINimum}.

Set syntax: MEASure:VOLTage:AC 1
:MEASure:VOLTage:AC 30m
:MEASure:VOLTage:AC 10mv
:MEASure:VOLTage:AC 10E-3
:MEASure:VOLTage:AC MAXimum
:MEASure:VOLTage:AC MINimum

Query syntax: MEASure: VOLTage:AC?

Return data 1.000000E-02 (Format is in <NR3>)

When the Level setup is current mode, the data returns 9.9E37.

<Command> :MEASure:VOLTage:DC <voltage NR3/disc>
:MEASure:VOLTage:DC?

Function:It sets or queries the DC measurement voltage (LEVEL).

Description:

Set parameter The value of DC voltage is {0.01~1|MAXimum|MINimum}.

Set syntax: MEASure:VOLTage:DC 10mv
:MEASure:VOLTage:DC 10E-3
:MEASure:VOLTage:DC 1
:MEASure:VOLTage:DC MAXimum
:MEASure:VOLTage:DC MINimum

Query syntax: MEASure:VOLTage:DC?

Return data 1.000000E-02 (Format is in <NR3>)

When the Level setup is current mode, the data returns 9.9E37.

<Command> :MEASure:CURREnt:AC <current NR3/disc>
:MEASure:CURREnt:AC?

Function:It sets or queries the AC measurement current (LEVEL).

Description:

Set parameter When RO(output impedance) is setting 100Ω , the setup value of AC current is {0.0001~0.02|MAXimum|MINimum}. When RO(output impedance) is setting 25Ω , the setup value of AC current is {0.0004~0.04|MAXimum|MINimum}.

Set syntax: MEASure:CURREnt:AC 0.01

:MEASure:CURRent:AC 20m
:MEASure:CURRent:AC 1E-2
:MEASure:CURRent:AC MAXimum
:MEASure:CURRent:AC MINimum

Query syntax:MEASure:CURRent:AC?

Return data 2.000000E-04 (Format is in <NR3>)

When the Level setup is voltage mode, the data returns 9.9E37.

<Command> :MEASure:ALC {OFF|ON|0|1}
:MEASure:ALC?

Function: It sets or queries the ALC.

Description:

Set parameter ON|1, OFF|0

Set syntax:MEASure:ALC ON

Query syntax:MEASure:ALC?

Return data When the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :MEASure:SMONitor {0|1|OFF |ON }
:MEASure:SMONitor?

Function: It sets or queries the DISPLAY Vm/Im

Description:

Set parameter ON|1, OFF|0

Set syntax:MEASure:SMONitor ON

Query syntax:MEASure: SMONitor?

Return data When the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :MEASure:AVERage <averageNR1>
:MEASure:AVERage?

Function: It sets or queries the AVERAGE.

Description:

Set parameter The value of the Average is {0~64}

Set syntax:MEASure:AVERageage 10

Query syntax: MEASure:AVERageage?

Return data 10 (Format is in <NR1>)

<Command> :MEASure:FONT {SMALl|LARGe}
:MEASure:FONT?

Function: It sets or queries the FONT SIZE.

Description:

Set parameter SMALl (small), LARGe (large)

Set syntax:MEASure:FONT LARGe

Query syntax:MEASure:FONT?

Return data LARG (Format is in <disc>)

<Command> :MEASure:TRIGger:DELay <delay time NR3/disc>

:MEASure:TRIGger:DElay?

Function:It sets or queries the TRIGGER DELAY.

Description:

Set parameterThe value of delay timeis {0.000~5.000|MAXimum|MINimum}.

Set syntax:MEASure:TRIGger:DElay 0.5

:MEASure:TRIGger:DElay 100ms

:MEASure:TRIGger:DElay 200ms

:MEASure:TRIGger:DElay 5E-3

:MEASure:TRIGger:DElay MAXimum

:MEASure:TRIGger:DElay MINimum

Query syntax:MEASure:TRIGger:DElay?

Return data 0.000 (Format is in <NR2>)

<Command> :MEASure:DElay <delay time NR3/disc>
:MEASure:DElay?

Function:It sets or queries the AC/DC DELAY.

Description:

Set parameterThe value of delay timeis {0.000~5.000|MAXimum|MINimum}.

Set syntax:MEASure:DElay 0.5

:MEASure:DElay 100ms

:MEASure:DElay 5E-3

:MEASure:DElay MAXimum

:MEASure:DElay MINimum

Query syntax:MEASure:DElay?

Return data 0.000 (Format is in <NR2>)

<Command> :MEASure:TRIGger:MODE {REPeat|0|SINGle|1|}

Function:It sets or queries the TRIGGER MODE.

Description:

Set parameterREPeat,0 (repeat) · SINGle,1 (single)

Set syntax:MEASure:TRIGger:MODE SINGle

Query syntax:MEASure:TRIGger:MODE?

Return data REP | SING (Format is in <disc>)

When the setup is 0, it returns REP , When the setup is 1, it returns SING .

<Command> :MEASure:RANGe:DC {1|2|3|4|AUTO|HOLD}
:MEASure:RANGe:DC?

Function:It sets or queries the DC RANGE.

Description:

Set parameter{1|2|3|4|AUTO|HOLD}

Set syntax:MEASure:RANGe:DC 2

:MEASure:RANGe:DC AUTO

Query syntax:MEASure:RANGe:DC

Return data 2 (Format is in <NR1>)

e

<Command> :MEASure:RANGe:AC {1|2|3|4|AUTO|HOLD}

Function:It sets or queries the AC RANGE.

Description:

Set parameter{1|2|3|4|AUTO|HOLD}

Set syntax:MEASure:RANGe:AC 3

:MEASure:RANGe:AC AUTO

Query syntax:MEASure:RANGe:AC

Return data 3 (Format is in <NR1>)

The range recommends setting as<Auto>in order to obtain better measuring accuracy. The range actually measured will be displayed at the lower-left corner of LCD panel. Further, there are also <1-30 Ω all frequency>, <2-300 Ω frequency below 1.2 MHz>, <3-3K Ω frequency below 120 KHz> and<4-30K Ω frequency below 12 KHz> ranges for option. Faster measuring speed can be achieved when setting at “Range Hold”.

<Command> :MEASure:OIMPedance {100|25}
:MEASure:OIMPedance?

Function:It sets or queries the RO.

Description:

Set syntax: MEASure:OIMPedance 100

Query syntax:MEASure:OIMPedance?

Return data 100(Format is in <NR1>)

<Command> :MEASure:COMParator:PARAMeter {1|2|3|4}
:MEASure:COMParator:PARAMeter?

Function:It sets or queries which parameters number is to be compared.

Description:

Set syntax:MEASure:COMParator:PARAMeter 3 (After this command, every compared setup is at this parameters number.)

Query syntax:MEASure:COMParator:PARAMeter?

Return data3 (Format is in <NR1>)

<Command> :MEASure:COMParator:STATe {OFF|ON|0|1}
:MEASure:COMParator:STATe?

Function:It sets or queries the COMP open or not.

Description:

Set syntax:MEASure:COMParator:STATe ON

Query syntax: MEASure:COMParator:STATe?

Return data When the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :MEASure:COMParator:MODE <ABSolute|DEViation|PERCent0|1|2>
:MEASure:COMParator:MODE?

Function: It sets or queries the COMP MODE.

Description:

Set parameter ABSolute,0|DEViation,1|PERCent,2

Set syntax: MEASure:COMParator:MODE PERCent

Query syntax: MEASure:COMParator:MODE?

Return data PERC (Format is in <disc>)

<Command> :MEASure:COMParator:NOMinal <nominal value NR3>
:MEASure:COMParator:NOMinal?

Function: It sets or queries the NOMINAL.

Description:

Set syntax: MEASure:COMParator:NOMinal 1000

:MEASure:COMParator:NOMinal 10K

:MEASure:COMParator:NOMinal 1E+05

Query syntax: MEASure:COMParator:NOMinal?

Return data 1.000000E+05 (Format is in <NR3>)

<Command> :MEASure:COMParator:UPPER <upper limit NR3>
:MEASure:COMParator:UPPER?

Function: It sets or queries the UPPER.

Description:

Set syntax: MEASure:COMParator:UPPER 1

:MEASure:COMParator:UPPER 100m

:MEASure:COMParator:UPPER 99999000000

Query syntax: MEASure:COMParator:UPPER?

Return data 9.999900E+10 (Format is in <NR3>)

<Command> :MEASure:COMParator:LOWER <LOWER limit NR3>

Function: It sets or queries the LOWER.

Description:

Set syntax: MEASure:COMParator:LOWER -1

:MEASure:COMParator:LOWER -1M

:MEASure:COMParator:LOWER -1E-05

Query syntax: MEASure:COMParator:LOWER?

Return data -1.000000E-05 (Format is in <NR3>)

<Command> :MEASure:COMParator:DISPlay <ABSolute|DEViation|PERCent0|1|2>
:MEASure:COMParator:DISPlay?

Function: It sets or queries the DISP MODE.

Description:

Set parameter ABSolute,0|DEViation,1|PERCent,2

Set syntax:MEASure:COMParator:MODE DEVIation

Query syntax:MEASure:COMParator:MODE?

Return dataDEV(Format is in <disc>)

<Command> :MEASure:BIN:PARAMeter
{OFF|RDC|LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B|E|U}
:MEASure:BIN:PARAMeter?

Function:It sets or queries the BIN Parameter.

Description:

Set syntax:MEASure:BIN:PARAMeter Z(only allow the parameter which is being used under the meter mode.)

Query syntax:MEASure:PARAMeter?

Return dataZ(Format is in <disc>)

<Command> :MEASure:BIN:NUMBER {2|3|4|5|6|7|8|9|MAXium|MINimum}
:MEASure:BIN:NUMBER?

Function:It sets or queries the BIN NUMBER.

Description:

Set parameterThe value of bin number is {2~9|MAXimum|MINimum}.

Set syntax:MEASure:NUMBER 4

Query syntax:MEASure:NUMBER?

Return data4(Format is in <NR1>)

<Command> :MEASure:BIN:METHod {EQUal|SEQuential|TOLerance|RANDom|0|1|2|3}
:MEASure:BIN:METHod?

Function:It sets or queries the BIN METHOD.

Description:

Set parameter EQUal/0, SEQuential/1, TOLerance/2, RANDom/3

Set syntax:MEASure:METHod SEQ

Query syntax:MEASure:METHod?

Return dataSEQ(Format is in <disc>)

<Command> :MEASure:BIN:MODE <ABSolute|DEVIation|PERCent|0|1|2>
:MEASure:BIN:MODE?

Function:It sets or queries the BIN MODE.

Description:

Set parameterABSolute,0|DEVIation,1|PERCent,2

Set syntax: MEASure:BIN:MODE DEVIation

Query syntax:MEASure:BIN:MODE:MODE?

Return data DEV(Format is in <disc>)

When the setup is 0, it returns ABS, When the setup is 1, it returns DEV, When the setup is 2, it returns PERC.

<Command> :MEASure:BIN:NOMinal <nominal value NR3 >
:MEASure:BIN:NOMinal?

Function:It sets or queries the BIN NOMINAL.

Description:

Set syntax:MEASure:BIN:NOMinal 1000
:MEASure:BIN:NOMinal 1K
:MEASure:BIN:NOMinal 1E+03
Query syntax:MEASure:BIN:NOMinal?
Return data 1.000000E+03 (Format is in <NR3>)

<Command> :MEASure:BIN:LIMit <nominal value NR3 >
:MEASure:BIN:LIMit?

Function:It sets or queries the BIN LIMIT.

Description:

Set syntax:MEASure:BIN:LIMit 0.001,100M,1k,1000k
Query syntax:MEASure:BIN:LIMit?
Return data +1.000000E-03, +1.000000E-01, +1.000000E+03, +1.000000E+06 (Format is in <NR3>)

<Command> :MEASure:FILE:LOAD <filename>

Function:It opens the meter mode's file.

Description:

Set syntax:MEASure:FILE:LOAD MICROTTEST.(load the file "MICROTTEST")

<Command> :MEASure:FILE:LOAD?

Function: It queries the meter mode's filename which is being using.

Description:

Set syntax:MEASure:FILE:LOAD?
Return dataMICROTTEST

<Command> :MEASure:FILE:NEW <file name>

Function: Create a new file named <file name>.

Description:

Set syntax:MEASure:FILE:NEW ABC

<Command> :MEASure:FILE:SAVE <file name>

Function: Save as a new file named <file name>, where the setting will be saved.

Description:

Set syntax:MEASure:FILE:SAVE ABC

<Command> :MEASure:FILE:DELEte <file name>

Function: Delete the file which named <file name>.

Description:

Set syntax :MEASure:FILE:DELEte ABC

<Command> :MEASure:BIAS:VOLTage<NR3>
:MEASure:BIAS:VOLTage?

Function: Set or query the DC bias voltage. Range -12.000V ~ +12.000

Description:

Set syntax :MEASure:BIAS:VOLTage -12
Query syntax :MEASure:BIAS:VOLTage?

Return data -1.200000E+01

<Command> :MEASure:BIAS:Current<NR3>
:MEASure:BIAS:Current?

Function: Set or query the DC bias current range.

Description:

Set syntax :MEASure:BIAS:Current 20

Query syntax :MEASure:BIAS:Current?

Return data +2.000000E+01

<Command> :MEASure:BIAS:STATe<ON|OFF|0|1>
:MEASure:BIAS:STATe?

Function: Set or query.

Description:

Set syntax :MEASure:BIAS:STATe ON

Query syntax :MEASure:BIAS:STATe?

Return data 1(ON), 0(OFF)

<Command> :MEASure:FILE?

Function: It queries all of the meter mode's filenames that are stored in the memory.

Description:

Query syntax: MEASure:FILE?

Return data N, filename1, filename2, filename3, ..., filenameN
where N= total file count

<Command> : MEASure:STATistic {ON|OFF|0|1}
: MEASure:STATistic?

Function: It sets or queries the statistic function in the meter mode.

Description:

Set parameter {ON|OFF|0|1}

Set syntax :MEASure:STATistic 1

Query syntax: MEASure:STATistic?

Return data 0|1

where 0 = statistic function is disabled.

1= statistic function is enabled.

<Command> :MEASure:STATistic:COUNt <pass count, fail count>
:MEASure:STATistic:COUNt?

Function: It sets or queries the statistical data in the meter mode.

Description:

Set parameter <pass count, fail count> (format is in NR1)

The value of pass count and fail count 0~999999999

Set syntax :MEASure:STATistic:COUNt 0,1

Query syntax :MEASure:STATistic:COUNt?

Return data n1,n2

where n1= pass count (format is in NR1)

n2= fail count (format is in NR1)

◆ FETCh Subsystem

<Command> :FETCh?

Function: It fetches the measurement data currently test mode

There are two options for trigger and query:

1. Give command *TRG or :TRIG? and get measuring result (recommend)
2. Give command :TRIG for trigger and give :FETCH? to get measuring result To be sure currently step is under MEAS mode, or give command :DISP:PAGE MEAS to enter MEAS mode.

<Command>:FETCH:SMONitor:DC?

Function: It queries the DC voltage and current.

Description:

Query syntax:FETCH:SMONitor:DC?

Return data 1.000000E-03,3.791975E-02 Vm,Im(Format is in <NR3>)

<Command>:FETCH:SMONitor:AC?

Function: It queries the AC voltage and current.

Description:

Query syntax:FETCH:SMONitor:AC?

Return data 1.000000E-03,3.791975E-02 Vm,Im(Format is in <NR3>)

<Command> : FETCh:MODE {0|1|QUERy|AUTO}
: FETCh:MODE?

Function: Sets or queries fetch mode for the instrument.

Description:

Set parameter 0|1|QUERy|AUTO

Set syntax:FETCH:MODE 1

Query syntax:FETCH:MODE?

When 0 or QUERy, The instrument send out the measurement data after receiving a query command.

When 1 or AUTO, When a measurement is completed, the instrument send out the measurement data automatically, even if it isn't triggered by command.

Under normal circumstance, the instrument returns the measurement data only when it receives a query or a measurement is triggered by a command over the interface such as "*TRG" or ":TRIG?".

Setting fetch mode to AUTO allows user to change this behavior. This function is especially useful when you need to collect data which is triggered from the handler or operator.

Care should be taken that the instrument resets the fetch mode to QUERY state at power-on.

◆ SYSTEM Subsystem

<Command> :SYST:ERR?

Function: It queries the error number in error message queue over the interface. The instrument has an error queue which is 64 errors deep and operates on a first-in, first-out basis, Repeatedly sending the query ":SYSTem:ERRor?" returns the error numbers in the order that they occurred until the queue is empty. Any further queries then return zeros until another error occurs.

When the queue is empty, the ERR message on the LCD screen is removed at the same time.

Description:

Query syntax :SYST:ERR?

Return data 0,"No error"
Common error code

- 0 No error
- 100 Command error
- 102 Syntax error
- 108 Parameter not allowed
- 109 Missing parameter
- 113 Undefined header
- 121 Invalid character in number
- 128 Numeric data not allowed
- 131 Invalid suffix
- 211 Trigger ignored
- 220 Parameter error
- 222 Data out of range
- 224 Illegal parameter
- 230 Data corrupt or stale
- 256 File not found
- 340 Calibration failed
- 350 Queue overflow
- 363 Input buffer overrun
- 410 Query interrupted

<Command> :SYST:VERSion?

Function: It queries the system version that includes software, firmware and calibration version.

Description:

Query syntax :SYST:VERSion?
Return data 1.350,20.0430,19.0521

<Command>:SYST:SER?

Function: It queries the serial number of the instrument.

Description:

Query syntax:SYST:SER?
Return data GEP000000

<Command> :SYST:BIAS {0|1|3} :SYST:BIAS?

Set parameter: {0|1|3}
Set syntax: :SYST:BIAS 1
Query syntax: :SYST:BIAS?
Return data: No return 0 | 12V return 1 | 622x/4x return 3

◆ CORRection Subsystem

<Command> :CORRection:OPEN :CORRection:OPEN?

Function:It sets or queries to do open correction.

Description:

Set syntax: CORRection:OPEN
Query syntax:CORRection:OPEN?

Return data When correction fail, it returns 0.
When correction passes, it returns 1.

<Command> :CORRection:SHORT
:CORRection:SHORT?

Function:It sets or queries to do short correction.

Description:

Set syntax: CORRection:SHORT

Query syntax:CORRection:SHORT?

Return data When correction fail, it returns 0.

When correction passes, it returns 1.

<Command> :CORRection:OPEN:STATe {OFF|ON|0|1}
:CORRection:OPEN:STATe?

Function:It sets or queries the status of open correction.

Description:

Set syntax:CORRection:OPEN:STATe ON

Query syntax:CORRection:OPEN:STATe?

Return dataWhen the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :CORRection:SHORT:STATe {OFF|ON|0|1}
:CORRection:SHORT:STATe?

Function:It sets or queries the status of short correction.

Description:

Set syntax:CORRection:SHORT:STATe ON

Query syntax:CORRection:SHORT:STATe?

Return dataWhen the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :CORRection:CABLe {0|0.5|1|2}
:CORRection:CABLe?

Function:It sets or queries the status of cable length correction.

Description:

Set syntax:CORRection:CABLe 1

Query syntax:CORRection:CABLe?

Return data0|0.5|1|2

<Command> :CORRection:HF
:CORRection:HF?

Function:It performs the high frequency load correction.

Description:

CORRection:HF To perform high frequency load correction with no result feedback.

CORRection:HF? To perform high frequency load correction with result feedback.

Set syntax: CORRection:HF

Query syntax: CORRection:HF?

Return data 0|1

where 0= The result of high frequency load correction is failed
1= The result of high frequency load correction is passed

<Command> :CORRection:HF:STATe {ON|OFF|0|1}
:CORRection:HF:STATe?

Function: It sets or queries the state of high frequency load correction.

Description:

Set parameter {ON|OFF|0|1}

Set syntax: CORRection:HF:STATe ON

Query syntax: CORRection:HF:STATe?

Return data 0|1

where 0= High frequency load correction function is disabled.

1= High frequenct load correction function is enabled.

<Command> :CORRection:LOAD
:CORRection:LOAD?

Function: It performs the spot load correction.

Description:

Set syntax: CORRection:LOAD

Query syntax: CORRection:LOAD?

Return data 1

where 1= The result of spot load correction is passed

<Command> :CORRection:LOAD:STATe {ON|OFF|0|1}
:CORRection:LOAD:STATe?

Function: It sets or queries the state of spot load correction.

Description:

Set parameter {ON|OFF|0|1}

Set syntax: CORRection:LOAD:STATe ON

Query syntax: CORRection:LOAD:STATe?

Return data 0|1

where 0= Spot load correction function is disabled.

1= Spod load correction function is enabled.

<Command> :CORRection:FIXTure {OFF|F42001|FX-000C20||FX-000C19|FX-000C12|
FX-000C10||FX-000C8|FX-000C7|FX-000C6}
:CORRection:FIXTure?

Function: It sets or queries the state of spot load correction.

Description:

Set syntax: CORRection:FIXTure OFF

Query syntax: CORRection:FIXTure?

Return data OFF

<Command> :CORRection:LOAD:SPOT <spot number 1-16>
:CORRection:LOAD:SPOT?

Function: It sets or queries the load correction spot number that has been currently edited.

Description:

Set parameter <spot number 1-16> (format is in NR1)

Set syntax: CORRection:LOAD:SPOT 1
Query syntax: :CORRection:LOAD:SPOT?
Return data 1

<Command> :CORRection:LOAD:FREQuency <frequency in NR3>
:CORRection:LOAD:FREQuency?

Function: It sets or queries the load frequency for the current load correction spot.

Description:

Set parameter <frequency> (format is in NR3),
where 0= FREQUENCY is OFF.
10HZ~30MHZ = FREQUENCY is ON.
Set syntax: CORRection:LOAD:FREQuency 100k
Query syntax: CORRection:LOAD:FREQuency?
Return data +1.000000E+05 (Format is in NR3).

<Command> :CORRection:LOAD:FUNCTion {LS-Q|LS-RS|LP-Q|LP-RP|CS-D|CS-RS|CP-D|CP-RP|R-X|G-B|Z-DEG|Y-DEG}
:CORRection:LOAD:FUNCTion?

Function It sets or queries the load function for the current load correction spot.

Description:

Set parameter {LS-Q|LS-RS|LP-Q|LP-RP|CS-D|CS-RS|CP-D|CP-RP|R-X|G-B|Z-DEG|Y-DEG}
Set syntax: CORRection:LOAD:FUNCTion LS-Q
Query syntax: CORRection:LOAD:FUNCTion?
Return data LS-Q

<Command> :CORRection:LOAD:REFeRence <reference A,reference B>
:CORRection:LOAD:REFeRence?

Function It sets or queries the load reference values for the current load correction spot.

Description:

Set parameter reference A,reference B (format is in NR3)
Set syntax: CORRection:LOAD:REFeRence 2E-03,40
Query syntax: CORRection:LOAD:REFeRence?
Return data +2.000000E-03,+4.000000E+01

<Command> :CORRection:LOAD:VALue <load A,load B>
:CORRection:LOAD:VALue?

Function It sets or queries the load values for the current load correction spot.

Description:

Set parameter load A,load B (format is in NR3)
Set syntax: CORRection:LOAD:VALue 2E+03,0.4
Query syntax: CORRection:LOAD:VALue?
Return data +2.000000E+03,+4.000000E-01

◆ LIST Subsystem

<Command> :LIST:STEP {1|2|3|4|...|14|15}
:LIST:STEP?

Function: It sets or queries the step of list mode.

Description:

Set parameter step number 1~15

Set syntax: LIST:STEP 1

Query syntax: LIST:STEP?

Return data 1 (Format is in <NR1>)

<Command> :LIST:PARAMeter
{OFF|RDC|LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B}
:LIST:PARAMeter?

Function: It sets or queries the measurement parameter of list mode.

Description:

Set parameter There is no E(Relative Permittivity) and U(Relative permeability) in the list mode.

Set syntax: LIST:PARAMeter Z

Query syntax: LIST:PARAMeter?

Return data Z (Format is in <disc>)

<Command> :LIST:FREQuency <frequencyNR3/disc>
:LIST:FREQuency?

Function: It sets or queries the measurement frequency of list mode.

Description:

Set parameter frequency 10.0~30000000.0 · MAXimum/MINimum °

Set syntax :LIST:FREQuency 1000

:LIST:FREQuency 1K

:LIST:FREQuency 1KHZ

:LIST:FREQuency 1E3

:LIST:FREQuency MAXimum

:LIST:FREQuency MINimum

Query syntax: LIST:FREQuency?

Return data 1.000000E+01 (Format is in <NR3>)

<Command> :LIST:VOLTage <voltage NR3/disc >
:LIST:VOLTage?

Function: It sets or queries the measurement voltage of list mode.

Description:

Set parameter When RO(output impedance) is setting 100Ω, the setup range of AC voltage is {0.01~2|MAXimum|MINimum}. When RO(output impedance) is setting 25Ω, the setup range of AC voltage is {0.01~1|MAXimum|MINimum}. The range of DC voltage is {0.01~1|MAXimum|MINimum}.

Set syntax: LIST:VOLTage 1

:LIST:VOLTage 10m

:LIST:VOLTage 10E-3
:LIST:VOLTage MAXimum
:LIST:VOLTage MINimum

Query syntax :LIST:VOLTage?

Return data 1.000000E-02 (Format is in <NR3>)

When the Level setup is current mode, the data returns 9.9E37.

<Command> :LIST:CURRent <current NR3/disc >
:LIST:CURRent?

Function: It sets or queries the measurement current of list mode.

Description:

Set parameter When RO(output impedance) is setting 100Ω, the setup range of AC current is {0.0001~0.02|MAXimum|MINimum}. When RO(output impedance) is setting 25Ω, the setup range of AC current is {0.0004~0.04|MAXimum|MINimum}. The range of DC current is {0.0002~0.04|MAXimum|MINimum}.

Set syntax :LIST:CURRent 0.01
:LIST:CURRent 10M
:LIST:CURRent 10E-3
:LIST:CURRent MAXimum
:LIST:CURRent MINimum

Query syntax:LIST:CURRent?

Return data 2.000000E-04 (Format is in <NR3>)

When the Level setup is current mode, the data returns 9.9E37.

<Command> :LIST:SPEED {MAXimum|FAST|MEDIUM|SLOW|SLOW2|0|1|2|3|4}
:LIST:SPEED?

Function: It sets or queries the SPEED of list mode.

Description:

Set parameter MAXimum/0, FAST/1, MEDIUM/2, SLOW/, SLOW2/4

Set syntax:LIST:SPEED 1
:LIST:SPEED FAST

Query syntax:LIST:SPEED?

Return data FAST (Format is in <disc>)

<Command> :LIST:DELAy <delay time NR3/disc>
:LIST:DELAy?

Function: It sets or queries the DELAY of list mode.

Description:

Set parameter The range of delay time is {0.000~5.000|MAXimum|MINimum}.

Set syntax:LIST:DELAy 0.5
:LIST:DELAy 500m
:LIST:DELAy 5E-3
:LIST:DELAy MAXimum
:LIST:DELAy MINimum

Query syntax:LIST:DELAy?

Return data 0.000 (Format is in <NR2>)

<Command> :LIST:COMParator:MODE <ABSolute|DEViation|PERCent|0|1|2>
:LIST:COMParator:MODE?

Function: It sets or queries the COMP MODE of list mode.

Description:

Set parameter ABSolute,0|DEViation,1|PERCent,2

Set syntax: MEASure:COMParator:MODE PERCent

Query syntax: LIST:COMParator:MODE?

Return data PERC (Format is in <disc>)

When the setup is 0, it returns ABS , When the setup is 1, it returns DEV , When the setup is 2, it returns PERC.

<Command> :LIST:COMParator:NOMinal <nominal value NR3 >
:LIST:COMParator:NOMinal?

Function: It sets or queries the NOMINAL of list mode.

Description:

Set syntax :LIST:COMParator:NOMinal 1000

:LIST:COMParator:NOMinal 10K

:LIST:COMParator:NOMinal 1E+04

Query syntax: LIST:COMParator:NOMinal?

Return data 1.000000E+04 (Format is in <NR3>)

<Command> :LIST:COMParator:UPPER <upper limit NR3>
:LIST:COMParator:UPPER?

Function: It sets or queries the UPPER of list mode.

Description:

Set syntax :LIST:COMParator:UPPER 1

:LIST:COMParator:UPPER 1m

:LIST:COMParator:UPPER 1E+01

Query syntax :LIST:COMParator:UPPER?

Return data 1.000000E+01 (Format is in <NR3>)

<Command> :LIST:COMParator:LOWER <LOWER limit NR3>
:LIST:COMParator:LOWER?

Function: It sets or queries the LOWER of list mode.

Description:

Set syntax :LIST:COMParator:LOWER -1

:LIST:COMParator:LOWER -1m

:LIST:COMParator:LOWER -1E+00

Query syntax :LIST:COMParator:LOWER?

Return data -1.000000E+00 (Format is in <NR3>)

<Command> :LIST:BIN:PARAMeter
{OFF|RDC|LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B|}
:LIST:BIN:PARAMeter?

Function: It sets or queries the BIN Parameter of list mode. ,

Description:

Set syntax :LIST:BIN:PARAMeter Z(only allow the parameter which is being used under the list mode.)

Query syntax :LIST:PARAMeter?

Return data Z (Format is in <disc>)

<Command> :LIST:BIN:NUMBER {2|3|4|5|6|7|8|9|MAXium|MINimum}
:LIST:BIN:NUMBER?

Function: It sets or queries the BIN NUMBER of list mode.

Description:

Set parameterThe value of bin number is {2~9|MAXimum|MINimum}.

Set syntax :LIST:NUMBER 4

Query syntax :LIST:NUMBER?

Return data 4 (Format is in <NR1>)

<Command> :LIST:BIN:METHod
{EQUal|SEQuential|TOLerance|RANDom|0|1|2|3}
:LIST:BIN:METHod?

Function: It sets or queries the BIN METHOD of list mode.

Description:

Set parameterEQUal,0| SEQuential,1|TOLerance,2 |RANDom,3

Set syntax :LIST:BIN:METHod SEQ

Query syntax :LIST:BIN:METHod?

Return data SEQ (Format is in <disc>)

<Command> :LIST:BIN:MODE <ABSolute|DEViation|PERCent|0|1|2>
:LIST:BIN:MODE?

Function: It sets or queries the BIN MODE of list mode.

Description:

Set parameter ABSolute,0|DEViation,1|PERCent,2

Set syntax :LIST:BIN:MODE DEViation

Query syntax :LIST:BIN:MODE?

Return data DEV (Format is in <disc>)

<Command> :LIST:BIN:NOMinal <nominal value NR3 >
:LIST:BIN:NOMinal?

Function: It sets or queries the BIN NOMINAL of list mode.

Description:

Set syntax :LIST:BIN:NOMinal 1000

:LIST:BIN:NOMinal 1K

:LIST:BIN:NOMinal 1E+03

Query syntax :LIST:BIN:NOMinal?

Return data 1.000000E+03 (Format is in <NR3>)

<Command> :LIST:BIN:LIMit <nominal value NR3 >
:LIST:BIN:LIMit?

Function: It sets or queries the BIN LIMIT of list mode.

Description:

Set syntax:LIST:BIN:BIN:LIMit 0.001,100M,1k,1000k

Query syntax:LIST:BIN:BIN:LIMit?

Return data +1.000000E-03, +1.000000E-01, +1.000000E+03, +1.000000E+06
(Format is in <NR3>)

<Command> :LIST:TRIGger:MODE {REPeat|SINGle|AUTO}
:LIST:TRIGger:MODE?

Function: It sets or queries the TRIGGER MODE of list mode.

Description:

Set parameter REPeat 、 SINGle 、 AUTO

Set syntax :LIST:TRIGger:MODE AUTO

Query syntax :LIST:TRIGger:MODE?

Return data AUTO (Format is in <disc>)

<Command> :LIST:TRIGger:DELAy <delay time NR3/disc>
:LIST:TRIGger:DELAy?

Function: It sets or queries the TRIGGER DELAY of list mode.

Description:

Set parameter The value of delay time is {0.000~5.000|MAXimum|MINimum}.

Set syntax :LIST:TRIGger:DELAy 0.5

:LIST:TRIGger:DELAy 500m

:LIST:TRIGger:DELAy 5E-3

:LIST:TRIGger:DELAy MAXimum

:LIST:TRIGger:DELAy MINimum

Query syntax :LIST:TRIGger:DELAy?

Return data 0.000 (Format is in <NR2>)

<Command> :LIST:OIMPedance {100|25}
:LIST:OIMPedance?

Function: It sets or queries the RO of list mode.

Description:

Set syntax :LIST:OIMPedance 25

Query syntax :LIST:OIMPedance?

Return data 25 (Format is in <NR1>)

<Command> :LIST:ALC {OFF|ON|0|1}

Function: It sets or queries the ALC of list mode.

Description:

Set syntax :LIST:ALC ON

Query syntax :LIST:ALC?

Return data When the setup is OFF, it returns 0.

When the setup is ON, it returns 1.

<Command> :LIST:BEEPer {OFF|PASS|OK|FAIL|NG|0|1|2}
:LIST:BEEPer?

Function: It sets or queries the BEEP WHEN of list mode.

Description:

Set parameter OFF, PASS|OK, FAIL|NG

Set syntax:LIST:BEEPer PASS

:LIST:BEEPer NG

:LIST:BEEPer OFF

Query syntax:LIST:BEEPer?

Return data PASS |FAIL |OFF (Format is in <disc>)

<Command> :LIST:RANGe {AUTO|HOLD|0|1}
:LIST:RANGe?

Function:It sets or queries the RANGE of list mode.

Description:

Set parameter If selecting <ON>, the measuring range is hold at the range, which is used by the first time measuring. If selecting <OFF>, the most suitable test range is set automatically.

Set syntax :LIST:RANGe AUTO

:LIST:RANGe 1

Query syntax :LIST:RANGe?

Return data AUTO |HOLD (Format is in <disc>)

<Command> :LIST:RETest {OFF|STEP|ALL|0|1|2}
:LIST:RETest?

Function: It sets or queries the FAIL RETEST of list mode.

Description:

Set parameterIt retests continuously until the test result is pass, when the test result is fail. If selecting <OFF>, it doesn't execute this function. If selecting <STEP 1>, only the first step is going to retest. If selecting <ALL>, no matter which step occur fail result, the fail step is going to retest until the result become pass.

Set syntax :LIST:RETest STEP

:LIST:RETest 2

:LIST:RETest OFF

Query syntax :LIST:RETest?

Return data OFF | STEP |ALL (Format is in <disc>)

<Command> :LIST:FILE:LOAD <filename>

Function:It opens the list mode's file.

Description:

Set syntax:MEASure:FILE:LOAD MICROTTEST.(open the MICROTTEST list mode file)

<Command> :LIST:FILE:LOAD?

Function:It queries the list mode's filename which is being using.

Description:

Query syntax:MEASure:FILE:LOAD?

Return data MICROTTEST

<Command> :LIST:FILE:NEW<file name>

Function: Create a new file named <file name>.

Description:

Set syntax :LIST:FILE:NEW ABC

<Command> :LIST:FILE:SAVE <file name>

Function: Save as a new file named <file name>, where the setting will be saved.

Description:

Set syntax :List:FILE:SAVE ABC

<Command> :LIST:FILE:DELEte <file name>

Function: Delete the file which named <file name>.

Description:

Set syntax :LIST:FILE:DELEte ABC

<Command> : LIST:BIAS:VOLTage <NR3>
: LIST:BIAS:VOLTage?

Function: It sets or queries the BIAS Voltage of list mode.

Description:

Set parameter: The value of BIAS Voltage -12.000~12.000

Set syntax: :LIST:BIAS:VOLTage 6

Query syntax :LIST:BIAS:VOLTage?

Return data +6.000000E+00

<Command> : LIST:BIAS:Current<NR3>
: LIST:BIAS:Current?

Function: With the 622X or 624X machine, set the BIAS SOURCE to Bias units
622x/624x on SYSTEM page.

Description:

Set parameter: The value of BIAS Current. 0A ~ 320A

Set syntax :LIST:BIAS:Current 20

Query syntax :LIST:BIAS:Current?

Return data: +2.000000E+01

<Command> :LIST:FILE?

Function:It queries all of the list mode's filenames that are stored in the memory.

Description:

Query syntax :LIST:FILE?

Return data N,filename1,filename2,filename3,...,filename N
where N= total file count

<Command> :LIST:STATistic {ON|OFF|0|1}
:LIST:STATistic?

Function: It sets or queries the statistic function in the list mode.

Description:

Set parameter {ON|OFF|0|1}

Set syntax: :LIST:STATistic 1

Query syntax: LIST:STATistic?

Return data 0|1

where 0= statistic function is disabled.
1= statistic function is enabled.

<Command> :LIST:STATistic:COUNt <pass count, fail count>

:LIST:STATistic:COUNT?

Function: It sets or queries the statistical data in the list mode.

Description:

Set parameter <pass count, fail count> (format is in NR1)

The value of pass count and fail count 0~999999999

Set syntax: :LIST:STATistic:COUNT 0,1

Query syntax :LIST:STATistic:COUNT?

Return data n1,n2

where n1= pass count (format is in NR1)

n2= fail count (format is in NR1)

◆ **SWEEP Subsystem**

<Command> :SWEep:TYPE {FREQuency|VAC|IAC|BIAS V}

:SWEep:TYPE?

Function: It sets or queries the TYPE.

Description:

Set parameter FREQuency | VAC(voltage) | IAC(current) | BIASV

Set syntax :SWEep:TYPE FREQuency

Query syntax :SWEep:TYPE?

Return data FREQ | VAC | IAC|BIASV (Format is in <disc>)

<Command> :SWEep:XAXis {LOGarithm|LINear}

:SWEep:XAXis?

Function: It sets or queries the XAXIS.

Description:

Set parameter LOGarithm | LINear

Set syntax :SWEep:XAXis LOGarithm

Query syntax :SWEep:XAXis?

Return data LOG | LIN (Format is in <disc>)

<Command> :SWEep:XAXis:DATA?

Function: It queries the XAXIS data.

Description:

Query syntax :SWEep:XAXis:DATA?

Return data

+1.000000E+03,+1.209960E+05,+2.409920E+05,+3.609880E+05,...+3.000000E+07 (Format is in <NR3>)

<Command> :SWEep:STARt <startNR3/disc>

:SWEep:STARt?

Function: It sets or queries the START.

Description:

Set parameter The start value of frequency is

{10.0~30000000.0|MAXimum|MINimum}.

The start value of voltage AC RO 100Ω is {0.01~2|MAXimum|MINimum}.

The start value of voltage AC RO 25Ω is {0.01~1|MAXimum|MINimum}.

The start value of current AC RO 100Ω is {0.0001~0.02|MAXimum|MINimum}.

The start value of current AC RO 25Ω is {0.0004~0.04|MAXimum|MINimum}.

The start value of BIAS V RO 100Ω is {-12~+12|MAXimum|MINimum}.

The start value of BIAS V RO 25Ω is {-12~+12|MAXimum|MINimum}.

Set syntax :SWEep:STARt 10
:SWEep:STARt 10m
:SWEep:STARt 1E+0
:SWEep:STARt MAXimum
:SWEep:STARt MINimum

Query syntax:SWEep:STARt?

Return data+1.000000E+01(Format is in <NR3>)

<Command> :SWEep:STOP <stopNR3/disc>
:SWEep:STOP?

Function:It sets or queries the STOP.

Description:

Set parameterThe stop value of frequency is
{10.0~30000000.0|MAXimum|MINimum}.

The stop value of voltage AC RO 100Ω is {0.01~2|MAXimum|MINimum}.

The stop value of voltage AC RO 25Ω is {0.01~1|MAXimum|MINimum}.

The stop value of current AC RO 100Ω is {0.0001~0.02|MAXimum|MINimum}.

The stop value of current AC RO 25Ω is {0.0004~0.04|MAXimum|MINimum}.

Set syntax :SWEep:STOP 10
:SWEep:STOP 10m
:SWEep:STOP 100E-4
:SWEep:STOP MAXimum
:SWEep:STOP MINimum

Query syntax:SWEep:STARt?

Return data+1.000000E+01(Format is in <NR3>)

<Command> :SWEep:FREQuency<frequencyNR3/disc>
:SWEep:FREQuency?

Function:It sets or queries the FREQ, when the TYPE setup is VAC or IAC.

Description:

Set parameterThe value of frequency is {10.0~30000000.0|MAXimum|MINimum}.

Set syntax :SWEep:FREQuency 1000
:SWEep:FREQuency 1K
:SWEep:FREQuency 1KHZ
:SWEep:FREQuency 1E3
:SWEep:FREQuency MAXimum
:SWEep:FREQuency MINimum

Query syntax:SWEep:FREQuency?

Return data 1.000000E+01(Format is in <NR3>)

When the TYPE setup is FREQuency mode, the data returns 9.9E37.

<Command> :SWEep:VOLTag <voltage NR3/disc>
:SWEep:VOLTag?

Function:It sets or queries the LEVEL to voltage mode, when the TYPE setup is FREQ.

Description:

Set parameter The value of voltage AC RO 100Ω is {0.01~2|MAXimum|MINimum}.

The value of voltage AC RO 25Ω is {0.01~1|MAXimum|MINimum}.

Set syntax :SWEep:VOLTage 1
:SWEep:VOLTage 1M
:SWEep:VOLTage 1MV
:SWEep:VOLTage 1E-3
:SWEep:VOLTage MAXimum
:SWEep:VOLTage MINimum

Query syntax:SWEep:VOLTage?

Return data 1.000000E+03(Format is in <NR3>)

When the LEVEL setup is not voltage mode, the data returns 9.9E37.

<Command> :SWEep:CURRent<currentNR3/disc>
:SWEep:CURRent?

Function:It sets or queries the LEVEL to current mode, when the TYPE setup is FREQ.

Description:

Set parameter The value of current AC RO 100Ω is {0.0001~0.02|MAXimum|MINimum}.

The value of current AC RO 25Ω is {0.0004~0.04|MAXimum|MINimum}.

Set syntax:SWEep:CURRent 0.01
:SWEep:CURRent 10m
:SWEep:CURRent 10E-3
:SWEep:CURRent MAXimum
:SWEep:CURRent MINimum

Query syntax:SWEep:CURRent?

Return data 1.000000E-04(Format is in <NR3>)

When the LEVEL setup is not current mode, the data returns 9.9E37.

<Command> :SWEep:TRIGger:MODE <REPeat|SINGle|0|1>
:SWEep:TRIGger:MODE?

Function:It sets or queries the TRIG.

Description:

Set parameter REPeat,0 (repeat) · SINGle,1 (single)

Set syntax:SWEep:TRIGger:MODE SINGle

Query syntax:SWEep:TRIGger:MODE?

Return data REP | SING (Format is in <disc>)

<Command> :SWEep:SPEEd {FAST|MEDium|SLOW|1|2|3}
:SWEep:SPEEd?

Function:It sets or queries the SPEED.

Description:

Set parameter FAST/1, MEDium/2, SLOW/3

Set syntax :SWEep:SPEEd 1
:SWEep:SPEEd FAST

Query syntax: :SWEep:SPEEd?

Return data FAST | MED | SLOW (Format is in <disc>)

<Command> :SWEep:TRACe {A|B}
:SWEep:TRACe?

Function: It sets or queries which trace is on using.

Description:

Set syntax: :SWEep:TRACe A

Query syntax: :SWEep:TRACe?

Return data A | B (Format is in <disc>)

<Command> :SWEep:TRACA:COLOR <0|1|2|3|4|5|6>
:SWEep:TRACA:COLOR?

Function: Change trace A line color.

Description:

Set syntax: :SWEep:TRACA:COLOR 1

Query syntax :SWEep:TRACA:COLOR?

Return data 1

1. Light blue
2. Light green
3. Light cyan
4. Light red
5. Pale magenta
6. Light yellow

<Command> :SWEep:TRACA:COLOR <0|1|2|3|4|5|6>
:SWEep:TRACA:COLOR?

Function: Change trace a color.

Description:

Set syntax: :SWEep:TRACA:COLOR 1

Query syntax :SWEep:TRACA:COLOR?

Return data 1

7. Light blue
8. Light green
9. Light cyan
10. Light red
11. Pale magenta
12. Light yellow

<Command> :SWEep:TRACA:COLOR <0|1|2|3|4|5|6>
:SWEep:TRACA:COLOR?

Function: Change trace a color.

Description:

Set syntax: :SWEep:TRACA:COLOR 1

Query syntax :SWEep:TRACA:COLOR?

Return data 1

13. Light blue

14. Light green
15. Light cyan
16. Light red
17. Pale magenta
18. Light yellow

<Command> :SWEep:TRACA:COLOR <0|1|2|3|4|5|6>
:SWEep:TRACA:COLOR?

Function: Change trace a color.

Description:

Set syntax: :SWEep:TRACA:COLOR 1

Query syntax :SWEep:TRACA:COLOR?

Return data 1

19. Light blue
20. Light green
21. Light cyan
22. Light red
23. Pale magenta
24. Light yellow

<Command> :SWEep:TRACB:COLOR <0|1|2|3|4|5|6>
:SWEep:TRACB:COLOR?

Function: Change trace B line color.

Description:

Set syntax: :SWEep:TRACB:COLOR 2

Query syntax :SWEep:TRACB:COLOR?

Return data 2

1. Light blue
2. Light green
3. Light cyan
4. Light red
5. Pale magenta
6. Light yellow

<Command> :SWEep:ANALysis:TRACA:COLor <0|1|2|3|4|5|6|7|8|9|10|11|12>

Function: Change trace A analysis line color.

Description:

Set syntax: :SWEep:ANALysis:TRACA:COLOR 7

Query syntax :SWEep:ANALysis:TRACA:COLOR?

Return data 7

0. OFF
1. Light blue
2. Light green
3. Light cyan-blue
4. Light red
5. Pale magenta

6. Light yellow
7. Deep blue
8. Deep green
9. Deep cyan-blue
10. Deep red
11. Deep magenta
12. Deep yellow

<Command> :SWEep:ANALysis:TRACB:COLor <0|1|2|3|4|5|6|7|8|9|10|11|12>

Function: Change trace B analysis line color.

Description:

Set syntax: :SWEep:ANALysis:TRACB:COLOR 8

Query syntax :SWEep:ANALysis:TRACB:COLOR?

Return data 8

0. OFF
1. Light blue
2. Light green
3. Light cyan-blue
4. Light red
5. Pale magenta
6. Light yellow
7. Deep blue
8. Deep green
9. Deep cyan-blue
10. Deep red
11. Deep magenta
12. Deep yellow

<Command> :SWEep:FUNCTion
 {LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B,OFF|LS|LP|CS|CP|Q|D|
 RS|RP|Z |DEG|RAD|R|X|Y|G|B }
 :SWEep:FUNCTion?

Function: It sets or queries the FUNC.

Description:

Set parameter The comma is placed between the two parameters. The first parameter can not set to OFF. There is no RDC (DC Resistance), E (Relative Permittivity) and U(Relative permeability) in the sweep mode.

Set syntax :SWEep:FUNCTion Z,DEG

Query syntax :SWEep:FUNCTion?

Return data Z,DEG(Format is in <disc>)

<Command> :SWEep:ANALysis:MODEl {A|B|C|D|E|F|G|OFF}
 :SWEep:ANALysis:MODEl?

Function: It sets or queries the ANALYSIS MODEL.

Description:

Set syntax:SWEep:ANALysis:MODEl B

Query syntax:SWEEP:ANALysis:MODEl?

Return data B(Format is in <disc>)

<Command> :SWEEP:DELay <delay timeNR3/disc>
:SWEEP:DELay?

Function: It sets or queries the SWEEP DELAY.

Description:

Set parameter The value of delay time is {0.000~5.000|MAXimum|MINimum}.

Set syntax :SWEEP:DELay 0.5
:SWEEP:DELay 500M
:SWEEP:DELay 500MS
:SWEEP:DELay 5E-3
:SWEEP:DELay MAXimum
:SWEEP:DELay MINimum

Query syntax:SWEEP:DELay?

Return data 0.000 (Format is in <NR2>)

<Command> :SWEEP:OIMPedance {100|25}
:SWEEP:OIMPedance?

Function: It sets or queries the OUTPUT IMPEDANCE.

Description:

Set syntax: SWEEP:OIMPedance 100

Query syntax:SWEEP:OIMPedance?

Return data 100 (Format is in <NR1>)

<Command> :SWEEP:KEEP {OFF|ON|0|1}
:SWEEP:KEEP?

Function: It sets or queries the KEEP PREVIOUS TRACE.

Description:

Set syntax :SWEEP:KEEP ON

Query syntax :SWEEP:KEEP?

Return data 1 | 0 (Format is in <disc>)

<Command> :SWEEP:TRACA:PARAMeter
{LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B|}
:SWEEP:TRACA:PARAMeter?

Function:It sets or queries the PARA of TRACE A

Description:

Set parameter The first parameter can't set to OFF. There is no RDC (DC Resistance), E (Relative Permittivity) and U (Relative permeability) in the sweep mode.

Set syntax :SWEEP:TRACA:PARAMeter Z

Query syntax :SWEEP:TRACA:PARAMeter?

Return data Z (Format is in <disc>)

<Command> :SWEEP:TRACA:YAXis {LOGarithm|LINear}
:SWEEP:TRACA:YAXis?

Function: It sets or queries the Y-AXIS of TRACE A.

Description:

Set parameter LOGarithm | LINear

Set syntax :SWEep:TRACA:YAXis LOGarithm

Query syntax :SWEep:TRACA:YAXis?

Return data LOG | LIN (Format is in <disc>)

<Command> :SWEep:TRACA:REFerence <value NR3>
:SWEep:TRACA:REFerence?

Function: It sets or queries the REF of TRACE A.

Description:

Set parameter It can set the value, when Y-AXIS setup is linear mode.

Set syntax :SWEep:TRACA:REFerence 25k

Query syntax :SWEep:TRACA:REFerence?

Return data 2.500000E+03 (Format is in <NR3>)

<Command> :SWEep:TRACA:POSition {-10 ~ 16|MAXimum|MINimum}
:SWEep:TRACA:POSition?

Function: It sets or queries the POS of TRACE A.

When Y-axis setup is LOG| LINEAR mode

Sets the LINEAR , POSition range is -5~5, Sets the LOGarithm , POSition range is -10~16

Description:

Set parameter {-10 ~ 16|MAXimum|MINimum}

Set syntax :SWEep:TRACA:POSition -3

Query syntax :SWEep:TRACA:POSition?

Return data -3 (Format is in <NR1>)

<Command> :SWEep:TRACA:DIVision <value NR3/disc>
:SWEep:TRACA:DIVision?

Function: It sets or queries the DIV of TRACE A.

Description:

Set parameter The numeric value can only set 1, 2, 5 and 10 (when Y-axis setup is linear mode).

Set syntax :SWEep:TRACA:DIVision 2k

Query syntax :SWEep:TRACA:DIVision?

Return data 2.000000E+03 (Format is in <NR3>)

Return data +9.9E37 (when Y-axis setup is not linear mode)

<Command> :SWEep:TRACA:DECade {1~12}
:SWEep:TRACA:DECade?

Function: It sets or queries the DECADE of TRACE A.

Description:

Set parameter The value of DECADE is {1~12} (when Y-axis setup is LOG mode).

Set syntax :SWEep:TRACA:DECade 5

Query syntax :SWEep:TRACA:DECade?

Return data 5 (Format is in <NR3>).

Return data +9.9E37 (when Y-axis setup is not LOG mode)

<Command> :SWEep:TRACA:MAXimum?

Function: It queries the maximum of TRACE A and corresponding frequency | voltage | current.

Description:

Query syntax :SWEep:TRACA:MAXimum?

Return data +2.230924E+06,+3.221517E-03 (Format is in <NR3>).The first data is the corresponding frequency | voltage | current. The second data is the maximum.

<Command> :SWEep:TRACA:MINimum?

Function: It queries the minimum of TRACE A and corresponding frequency | voltage | current.

Description:

Query syntax:SWEep:TRACA:MINimum?

Return data +2.310130E+06,-3.446227E-03 (Format is in <NR3>).The first data is the corresponding frequency | voltage | current. The second data is the minimum.

<Command> :SWEep:TRACA:RESult?

Function: It queries all of the value data of TRACE A.

Description:

Query syntax:SWEep:TRACA: RESult?

Return data +2.218913E-04,+2.215632E-04,+2.216804E-04...(Format is in <NR3>).

<Command> :SWEep:TRACB:PARAMeter
{LS|LP|CS|CP|Q|D|RS|RP|Z|DEG|RAD|R|X|Y|G|B|}
:SWEep:TRACA:PARAMeter?

Function: It sets or queries the PARA of TRACE B

Description:

Set parameterThe first parameter can not set to OFF. There is no RDC(DC Resistance), E(Relative Permittivity) and U(Relative permeability) in the sweep mode.

Set syntax:SWEep:TRACB:PARAMeter Z

Querysyntax:SWEep:TRACB:PARAMeter?

Return data Z (Format is in <disc>)

<Command> :SWEep:TRACB:YAXis {LOGarithm|LINear}
:SWEep:TRACB:YAXis?

Function: It sets or queries the Y-AXIS of TRACE A.

Description:

Set parameterLOGarithm | LINear

Set syntax:SWEep:TRACB:YAXis LOGarithm

Query syntax:SWEep:TRACB:YAXis?

Return data LOG | LIN (Format is in <disc>)

<Command> :SWEep:TRACB:REFerence <value NR3>
:SWEep:TRACB:REFerence?

Function: It sets or queries the REF of TRACE B.

Description:

Set parameter It can set the value, when Y-AXIS setup is linear mode.

Set syntax: SWEep:TRACB:REFeRence 25k

Query syntax: SWEep:TRACB:REFeRence?

Return data 2.500000E+03 (Format is in <NR3>)

<Command> :SWEep:TRACB:POSition {-10 ~ 16|MAXimum|MINimum}
:SWEep:TRACB:POSition?

Function: It sets or queries the POS of TRACE B.

Description:

Set parameter {-10 ~ 16|MAXimum|MINimum}

Set syntax :SWEep:TRACB:POSition -3

Query syntax :SWEep:TRACB:POSition?

Return data -3 (Format is in <NR1>)

<Command> :SWEep:TRACB:DIVision <value NR3/disc>
:SWEep:TRACB:DIVision?

Function: It sets or queries the DIV of TRACE B.

Description:

Set parameter The numeric value can only set 1, 2, 5 and 10 (when Y-axis setup is linear mode).

Set syntax :SWEep:TRACB:DIVision 2k

Query syntax :SWEep:TRACB:DIVision?

Return data 2.000000E+03 (Format is in <NR3>)

Return data +9.9E37 (when Y-axis setup is not linear mode)

<Command> :SWEep:TRACB:DECade {1~12}
:SWEep:TRACB:DECade?

Function: It sets or queries the DECADE of TRACE B.

Description:

Set parameter The value of DECADE is {1~12} (when Y-axis setup is LOG mode).

Set syntax: SWEep:TRACB:DECade 5

Query syntax: SWEep:TRACB:DECade?

Return data 5 (Format is in <NR3>).

Return data +9.9E37 (when Y-axis setup is not LOG mode)

<Command> :SWEep:TRACB:MAXimum?

Function: It queries the maximum of TRACE B and corresponding frequency | voltage | current.

Description:

Query syntax: SWEep:TRACB:MAXimum?

Return data +2.230924E+06, +3.221517E-03 (Format is in <NR3>). The first data is the corresponding frequency | voltage | current. The second data is the maximum.

<Command> :SWEep:TRACB:MINimum?

Function: It queries the minimum of TRACE B and corresponding frequency | voltage | current.

Description:

Query syntax: SWEep:TRACB:MINimum?

Return data +2.310130E+06,-3.446227E-03 (Format is in <NR3>). The first data is the corresponding frequency | voltage | current. The second data is the minimum.

<Command> :SWEep:TRACB:RESult?

Function: It queries all of the value data of TRACE B.

Description:

Query syntax: SWEep:TRACB: RESult?

Return data +2.218913E-04,+2.215632E-04,+2.216804E-04...(Format is in <NR3>).

<Command> :SWEep:AUToscale

Function: It does the AUTO FIT function.

Description:

Set syntax: SWEep:AUToscale

<Command> :SWEep:RESult?

Function: It queries all of the value data of TRACE A and TRACE B.

Description:

Query syntax: SWEep:RESult?

Return data +2.218913E-04,+2.215632E-04,+2.216804E-04...(Format is in <NR3>). It uploads the TRACE A data at the beginning. It start uploading TRACE B data when finish uploading TRACE A data.

<Command> :SWEep:ANALysis:RESult?

Function: It queries all of the value data and corresponding frequency | voltage | current of TRACE A and TRACE B.

Description:

Query syntax :SWEep:ANALysis:RESult?

Return data +1.000000E+03 , +2.212126E-04 , +1.398695E+00 , +1.035500E+03 , +2.209532E-04 , +1.446218E+00...(Format is in <NR3>). It uploads the TRACE A data at the beginning. It starts uploading TRACE B data when finish uploading TRACE A data.

<Command> :SWEep:ANALysis:CALCulate?

Function: It queries the data of R1, L1, C1, C0 and R0 which are in the ANALYSIS mode.

Description:

Query syntax: SWEep:ANALysis:CALCulate?

Return data +1.076054E+05 , +2.209770E-04 , +2.138633E-11 , +1.588589E-01 (Format is in <NR3>).

<Command> :SWEep:SRF:SERies?

Function: It queries the SRF fs (self-resonant frequency serial).

Description:

Query syntax: SWEep:SRF:SERies?

Return data +2.310130E+06 (Format is in <NR3>).

<Command> :SWEep:SRF:PARallel?

Function: It queries the SRF fp (self-resonant frequency parallel).

Description:

Query syntax :SWEep:SRF:PARallel?

Return data +2.310130E+06 (Format is in <NR3>).

<Command> :SWEep:BIAS:Voltage <value NR3>
:SWEep:BIAS:Voltage?

Function: It sets or queries the BIAS Voltage of sweep mode.

Description:

Set parameter: The value of BIAS Voltage on sweep mode -12.000~12.000

Set syntax: :SWEep:BIAS:Voltage 6

Query syntax: :SWEep:BIAS:Voltage?

Return data +6.000000E+00

<Command> :SWEep:BIAS:Current <value NR3>
:SWEep:BIAS:Current?

Function: With the 622X or 624X machine, set the BIAS SOURCE to Bias units
622x/624x on SYSTEM page.

Description:

Set parameter: The value of BIAS Current. 0A ~ 320A

Set syntax: :SWEep:BIAS:Current 20

Query syntax: :SWEep:BIAS:Current?

Return data: +2.000000E+01

◆ **Read the measured value**

Read the measured value

Read Data format under Meter Mode

<para 1 data>, <para 2 data>, <para 3 data>, <para 4 data>, <status>, <bin number>, <para 1 compare status>, <para compare status>, <para 3 compare status>, <para 4 compare status>

para 1-4 data

During value measuring, not all of four values will be displayed. The value will be displayed when the opening display parameters are available. For example, if only two parameters are opened, then only two counts of value will be transmitted.

status – Measuring status, and the weighted value of each status refers to the final value.

0 – Normal status without special status and without comparison.

1 – Measuring schedule error

2 – ALC error

4 – Other errors

8 – Reserve

16 – All parameters OK

32 – Some parameters NG

bin number – Categorization result, and such value will not be displayed when closing the bin function.

-1 – bin out, not in the categorization number

1 – 9 – bin number, the categorization result is 1-9.

para compare status 1-4

Measuring comparison result: If any parameter comparison function is opened, then the comparison result will be displayed for all of the opened parameters.

0 – No comparison

1 – Parameter comparison result OK

2 – Parameter comparison result NG

Value transmit mode under Multi-step Test Mode.

<result>, <direction>, <bin number>, <step 1 result>, <step 1 data>, <step 2 result>, <step 2 data>, <step 3 result>, <step 3 data>.....<step n result>, <step n data>

result – Finally judged test result

0 – Test not interrupted. Not completed

1 – Test steps all OK

2 – NG occurs to the test step

bin number - categorization result, and such value will not be displayed when closing the bin function.

-1 - bin out not in the categorization number

1-9 - bin number the categorization result is 1-9

step result

0 – no test

1 – test OK

2 – test NG

step data


test value

◆ Basic measurement principle

To measure capacitance, inductance and resistance user can select series or parallel mode.

C (Capacitance) :

Series mode:




Series mode Equations:

$$C_s = C_p (1 + D^2)$$

D = dissipation factor

Parallel mode:



Parallel mode Equations:

$$C_p = \frac{C_s}{(1 + D^2)}$$

D = dissipation factor

L (Inductance) :

Series mode:




Series mode Equations:

$$L_s = \frac{L_p}{\left(1 + \frac{1}{Q^2}\right)}$$

Q = Quality Factor

Parallel mode:




Parallel mode Equations:

$$L_p = L_s \left(1 + \frac{1}{Q^2}\right)$$

Q = Quality Factor

R (Resistance) :

Series mode:




Series mode Equations:

$$R_s = \left(\frac{R_p}{1 + Q^2} \right)$$

Q = Quality Factor

Parallel mode:



Parallel mode Equations:

$$R_p = R_s (1 + Q^2)$$

Q = Quality Factor

◆ Resistance (R) and Conductance (G)

The resistance is a measure of the difficulty to pass an electric current through that conductor. The SI unit of resistance is the “ohm” (Ω). The inverse quantity is electrical conductance, and this is the ease with which an electric current passes through a circuit. The SI unit of conductance is measured in Siemens (S) and it the reciprocal of the resistance ($G=1/R$).

● Resistance (R)

Measure Type: Series mode $\rightarrow R_s$ / Parallel mode $\rightarrow R_p$ / DC mode $\rightarrow R_{dc}$

Relevant Equations:

$$R = \frac{V}{I} = \frac{1}{G} = Z_s - jX = Z_s - j\omega L = Z_s + \frac{j}{\omega C}$$

$$|Z_s| = \sqrt{(R^2 + X^2)}$$

$$|Z_p| = \frac{RX}{\sqrt{(R^2 + X^2)}}$$

$$R_s = |Z| \cos \theta$$

● Conductance (G)

Measure Type: Parallel mode $\rightarrow G_p$ (Conductance is measuring by parallel mode only.)

Relevant Equations:

$$G_p = \frac{I}{V} = \frac{1}{R} = Y_p - jB = Y_p - j\omega C = Y_p + \frac{j}{\omega L}$$

$$|Y_s| = \frac{GB}{\sqrt{(G^2 + B^2)}}$$

$$|Y_p| = \sqrt{(G^2 + B^2)}$$

$$G_p = |Y| \cos \theta$$

◆ Capacitance (C)

Capacitance (denoted by the letter C) is the ability of a body to store an electrical charge at a given potential difference between its plates. The SI unit of capacitance is the farad (symbol: F).

Measure Type: Series mode → Cs / Parallel mode → Cp

Relevant Equations:

$$Z_s = R + jX = R + j\omega L = R - \frac{j}{\omega C}$$

$$Y_p = G + jB = G + j\omega C = G - \frac{j}{\omega L}$$

$$Q = \frac{\omega L_s}{R_s} = \frac{1}{\omega C_s R_s} \quad (\text{series R, L, C values})$$

$$Q = \frac{R_p}{\omega L_p} = \omega C_p R_p \quad (\text{parallel R, L, C values})$$

$$D = \frac{R_s}{\omega L_s} = \omega C_s R_s \quad (\text{series R, L, C values})$$

$$D = \frac{G_p}{\omega C_p} = \omega L_p G_p \quad (\text{parallel G, L, C values})$$

◆ Inductance (L)

Inductance is the property of an electrical conductor by which a change in current through it induces an electromotive force (EMF) in both the conductor itself and in any nearby conductors by mutual inductance. In the SI system, the measurement unit for inductance is the Henry (with the unit symbol H).

Measure Type: Series mode → Cs / Parallel mode → Cp

Relevant Equations:

$$Z_s = R + jX = R + j\omega L = R - \frac{j}{\omega C}$$

$$Y_p = G + jB = G + j\omega C = G - \frac{j}{\omega L}$$

$$Q = \frac{\omega L_s}{R_s} = \frac{1}{\omega C_s R_s} \quad (\text{series R, L, C values})$$

$$Q = \frac{R_p}{\omega L_p} = \omega C_p R_p \quad (\text{parallel R, L, C values})$$

$$D = \frac{R_s}{\omega L_s} = \omega C_s R_s \quad (\text{series R, L, C values})$$

$$D = \frac{G_p}{\omega C_p} = \omega L_p G_p \quad (\text{parallel G, L, C values})$$

◆ Reactance (X) and Susceptance (B)

In AC circuit analysis, reactance is represented by the capital letter “X” which is the imaginary part of complex impedance. Reactance is the opposition of a circuit element to a change in the current or voltage, due to that element's inductance or capacitance which is similar to the opposition of resistance to current in a DC circuit. In an AC circuit (e.g. a series RLC circuit) inductance and capacitance may oppose current and are named reactance measured in units of Ohm (Ω).

In electrical engineering, susceptance (B) is the imaginary part of admittance. The inverse of admittance is impedance, and the real part of admittance is conductance. The latter is the reciprocal of impedance ($B=1/X$) and is measured in units of Siemens (S).

● Reactance (X):

Measure Type: Series mode → X_s (Reactance is measuring by series mode only.)

Relevant Equations:

$$X = \frac{1}{B} = |Z| \sin \theta$$

$$|Z_s| = \sqrt{(R^2 + X^2)}$$

$$|Z_p| = \frac{RX}{\sqrt{(R^2 + X^2)}}$$

$$X_s = |Z| \sin \theta$$

● Susceptance (B):

Measure Type: parallel mode → B_p (Reactance is measuring by parallel mode only.)

Relevant Equations:

$$B = \frac{1}{X} = |Y| \sin \theta$$

$$|Y_s| = \frac{GB}{\sqrt{(G^2 + B^2)}}$$

$$|Y_p| = \sqrt{(G^2 + B^2)}$$

$$B_p = |Y| \sin \theta$$

◆ Impedance (Z) and Admittance (Y)

The impedance covers oppositions in AC circuits including resistance, inductance, and capacitance and is measured in units of Ohm (Ω).

In electrical engineering, admittance covers both conductance and susceptance and is the reciprocal of impedance. It is measured in units of Siemens (S).

● Impedance (Z):

Relevant Equations:

$$Z = \frac{E}{I} = \frac{1}{Y}$$

$$Z_s = R + jX = R + j\omega L = R - \frac{j}{\omega C}$$

$$|Z_s| = \sqrt{(R^2 + X^2)}$$

$$|Z_p| = \frac{RX}{\sqrt{(R^2 + X^2)}}$$

$$R_s = |Z| \cos \theta$$

$$X_s = |Z| \sin \theta$$

● Admittance (Y):

Relevant Equations:

$$Y = \frac{I}{E} = \frac{1}{Z}$$

$$Y_p = G + jB = G + j\omega C = G - \frac{j}{\omega L}$$

$$|Y_s| = \frac{GB}{\sqrt{(G^2 + B^2)}}$$

$$|Y_p| = \sqrt{(G^2 + B^2)}$$


$$G_p = |Y| \cos \theta$$

$$B_p = |Y| \sin \theta$$

◆ Quality factor (Q) and Dissipation factor (D)

The quality factor measures energies consumed by relative frequency. In general, the better a circuit's quality factor the better its selectivity.

The dissipation factor is the reciprocal of quality factor. It is the signal angle loss by a capacitor (or inductor) and acting frequency at a fixed temperature. Phase shifts caused by time lag between an externally applied voltage and current generated may result in loss of current and energy dissipation. Here the total current (I) is the sum of the charging current (I_c) by a 90° voltage phase shift and loss current (I_R) of the same voltage. The loss angle is the angle δ between the total current and charging current and $\tan\delta$ the dissipation factor (symbol: D) as shown in the figure below:



● Quality factor (Q)

Relevant Equations:

$$Q = \frac{R_p}{\omega L_p} = \omega C_p R_p \quad (\text{series R, L, C values})$$

$$Q = \frac{\omega L_s}{R_s} = \frac{1}{\omega C_s R_s} \quad (\text{series R, L, C values})$$

$$Q = \frac{1}{\tan(90 - \theta)^\circ} = \frac{1}{D}$$

- Dissipation factor (D)

Relevant Equations:

$$D = \frac{R_s}{\omega L_s} = \omega C_s R_s$$

$$D = \frac{G_p}{\omega C_p} = \omega L_p G_p$$

$$D = \tan(90 - \theta)^\circ = \frac{1}{Q}$$

- ◆ Phase angle (θ)

This is the shift angle when measuring impedance (Z), admittance (Y), quality factor (Q) and dissipation factor (D).

Relevant equations:

$$Z_s = R + jX = R + j\omega L = R - \frac{j}{\omega C}$$

$$Y_p = G + jB = G + j\omega C = G - \frac{j}{\omega L}$$


$$Y_p = G + jB = G + j\omega C = G - \frac{j}{\omega L}$$

$$Q = \frac{1}{\tan(90 - \theta)^\circ} = \frac{1}{D} \quad D = \tan(90 - \theta)^\circ = \frac{1}{Q}$$

$$R_s = |Z| \cos \theta \quad X_s = |Z| \sin \theta$$



$$G_p = |Y| \cos \theta \quad B_p = |Y| \sin \theta$$

◆ Overall Impedance Measurement Theory



The simplified model of the 6630 impedance measurement, V_s is the test signal voltage and R_o is source resistance. If the current across the DUT is I when a test signal voltage V is applied, the DUT's impedance, Z , is expressed by $Z = \frac{V}{I}$.

Impedance, Z , contains real and imaginary parts. The figure shows vector representation of impedance as follow.




$$Z = R + jX = |Z| \angle \theta$$

$$\begin{cases} R = |Z| \cos \theta \\ X = |Z| \sin \theta \end{cases}$$

$$\begin{cases} |Z| = \sqrt{R^2 + X^2} \\ \theta = \tan^{-1} \left(\frac{X}{R} \right) \end{cases}$$

R: Resistance
X: Reactance
|Z|: Impedance
 θ : Phase Angle

Impedance, Z , can also be expressed as admittance, Y . Admittance is expressed in terms of impedance, Z , by $Y = \frac{1}{Z}$.





$$Y = \frac{1}{Z} = \frac{1}{R+jX} = \frac{R}{R^2+X^2} - j \frac{X}{R^2+X^2}$$

OR


$$Y = \frac{1}{Z} = \frac{1}{|Z|\angle\theta} = |Y|\angle(-\theta)$$

For parallel connected circuits, it is better to use admittance, Y .



$$Z = \frac{jRX}{R+jX} = \frac{RX^2}{R^2+X^2} + j \frac{R^2X}{R^2+X^2}$$

(Impedance make it a bit complex)











$$Y = G + jB$$

G : Conductance

B : Susceptance

$|Y|$: Admittance

The 6630 measures a DUT's impedance, Z , which is a vector value, and gives the result using the following equivalent circuits.

		$Z = R_s + jX = Z \angle \theta$ $X = \omega L_s$ $Z = R_s + j \omega L_s$ <p>Where $\omega = 2 \pi f$ (f : test frequency)</p>
		$Z = R_s + jX = Z \angle \theta$ $X = \omega L_s$ $Z = R_s + j \omega L_s$ <p>Where $\omega = 2 \pi f$ (f : test frequency)</p>
		$Z = R_s + jX = Z \angle \theta$ $X = -j \frac{1}{\omega C_s}$ $Z = R_s - j \frac{1}{\omega C_s}$ <p>Where $\omega = 2 \pi f$ (f : test frequency)</p>
		$Y = G + jB$ $B = \omega C_p$ $Y = G - j \omega C_p$ <p>Where $\omega = 2 \pi f$ (f : test frequency)</p>
$Q = \frac{1}{D} = \frac{1}{\tan \delta} = \frac{X_L}{R} = \frac{-X_C}{R} = \frac{-B_L}{G} = \frac{B_C}{G}$		



L_p : Parallel Inductance
 L_s : Series Inductance
 Q : Quality factor

C_p : Parallel Capacitance
 C_s : Series Capacitance
 D : Dissipation factor

◆ Characteristics Example

As can be seen in the following figure, a component can have different effective parameter values dependent upon its operating condition. The measured values most useful in actual applications are obtained from precise measurement under the actual operating conditions.

Dut	Characteristics Example	Measurement Functions
Large C		Cs-Rs Cs-D Cs-Q R-X $ Z -\angle\theta$
Small C		Cp-G Cp-D Cp-Q G-B $Y-\angle\theta$
Large L		Lp-G Lp-D Lp-Q G-B $Y-\angle\theta$
Small L		Ls-Rs Ls-D Ls-Q R-X $ Z -\angle\theta$

Dut	Characteristics Example	Measurement Functions
Large R		Cp-G G-B Y- $\angle\theta$
Small R		Ls-Rs R-X Z - $\angle\theta$

◆ High and low impedance criteria

The following criteria can be used to roughly discriminate between low, middle, and high impedances by following figure. The medium Z range may be covered with an extension of either the low Z or high Z range. These criteria differ somewhat, depending on the frequency and component type.

In the frequency region where the primary capacitance or inductance of a component exhibits almost a flat frequency response, either a series or parallel equivalent circuit can be applied as a suitable model to express the real impedance characteristic. Practically, the simplest series and parallel models are effective in most cases when representing characteristics of general capacitor, inductor, and resistor components.

