0x29(41) +KP*7	-1999 ÷ 18000	parameter 13+KP*7: 🖬 lower limit or bottom of the indication range	R/W
0x2A (42) +KP*7	-1999 ÷ 18000	parameter 14+KP*7: 🎹 upper limit or top of the indication range	R/W
0x2B (43) +KP*7	-500 ÷ 500	parameter 15+KP*7: Re zero offset for measurements	R/W
0x2C (44) +KP*7	850 ÷ 1150	parameter 16+KP*7: EECalibration of inclination (sensitivity) for measurements	R/W
0x34 (52)	0 ÷ 4	parameter 24: co5 1 control signal for output 1 (assignment of input)	R/W
0x35 (53)	0 ÷ 3	parameter 25: Fto I failure status of output 1	R/W
0x36 (54)	0 ÷ 3	parameter 26: Fun I function of output 1	R/W
0x37 (55)	-1999 ÷ 18000	parameter 27: SEE preset value 1	R/W
0x38 (56)	0 ÷ 9999	parameter 28: 🗷 hysteresis of output 1	R/W
0x39 (57)	0 ÷ 4	parameter 29: 205 control signal for output 2 (assignment of input)	R/W
0x3A (58)	0 ÷ 3	parameter 30: For failure status of output 2	R/W
0x3B (59)	0 ÷ 10	parameter 31: un I function of output 2	R/W
0x3C (60)	-1999 ÷ 18000	parameter 32: EEE preset value 2	R/W
0x3D (61)	0 ÷ 9999	parameter 33: A hysteresis of output 2	R/W
0x3E (62)	0 ÷ 1	parameter 34: RESP type of analogue output	R/W
0x3F (63)	0 ÷ 4	parameter 35: co51 control signal (input) for analog output	R/W
0x40 (64)	0 ÷ 3	parameter 36: Fund function of analogue output	R/W
0x41 (65)	-1999 ÷ 18000	parameter 37: R-La lower indication for retransmission	R/W
0x42 (66)	-1999 ÷ 18000	parameter 38: A-H upper indication for retransmission	R/W
0x36 (67)	0 ÷9	parameter 39: Function	R/W
0x3A (68)	3 ÷ 360	parameter 40: 💶 pulsation period for outputs 1, 2 in manual mode	R/W
0x3B (69)	0 ÷ 100	parameter 41: #555 preset value of the manual mode	R/W
0x40 (70)	0 ÷ 3	parameter 42: 5555 value change block 555 1, 5552	R/W
0x41 (71)	0 ÷ 9999	parameter 43: PR55 password	R/W
0x42 (72)	1 ÷ 2	parameter 44: PPro protection of the configuration with a password	R/W
0x44 (73)	1 ÷ 247	parameter 45: Reder MODBUS-RTU address in the RS485 network	R/W
0x45 (74)	0 ÷ 5	parameter 46: F speed for RS485	R/W

Comments:

(1) The data is saved in the volatile (not subject to wear) memory of the SRAM type; other parameters are additionally saved in the non-volatile memory (subject to wear) of the FLASH type only at the time of power shutdown and provided that the settings have been changed.

17. USER'S NOTES



X

APAR - Sales Office 05-090 Raszyn, ul. Gałczyńskiego 6, Poland tel. (+48) 22-101-27-31, 22-853-48-56, 22-853-49-30 fax (+48) 22-101-27-33 Internet: www.apar.pl, email: automatyka@apar.pl

User instruction

UNIVERSAL DISPLAYS

two-channel with alarms and clock



AR540



AR751



Thank you for choosing our product.

This instruction is intended to facilitate correct operation, safe use, and taking full advantage of the display's functionalities.

Before you start the device, please read and understand this instruction.

In the event of any additional questions, please contact our technical adviser.

CONTENTS

1. SAFETY RULES	3
2. INSTALLATION GUIDELINES	3
3. GENERAL CHARACTERISTICS OF THE DISPLAY	3
4. CONTENTS OF THE PACKAGE	4
5. TECHNICAL DATA	4
6. ENCLOSURE DIMENSIONS AND INSTALLATION DATA	б
7. DESCRIPTION OF TERMINAL STRIPS AND ELECTRICAL CONNECTIONS	7
8. IMPORTANT COMMENTS PERTAINING TO OPERATION	8
9. FUNCTIONS OF BUTTONS AND LED INDICATORS. MINIMUM AND MAXIMUM VIEW	8
9.1. BINARY INPUT	9
10. SETTING OF THE CONFIGURATION PARAMETERS	10
11. QUICK ACCESS MENU	14
12. OUTPUT OPERATION CONFIGURATION	14
12.1. CHANGING THE PRESET OUTPUT VALUES	14
12.2. TYPES OF OUTPUT CHARACTERISTICS	15
12.3. ANALOG OUTPUT	16
12.4. MANUAL AND REMOTE CONTROL FUNCTION	16
13. MESSAGE AND ERROR SIGNALING	16
14. CONNECTING THE CONTROLLER TO A COMPUTER AND AVAILABLE SOFTWARE	17
15. RS485 COMMUNICATION INTERFACE (acc. to EIA RS-485)	18
16. MODBUS-RTU SERIAL TRANSMISSION PROTOCOL (SLAVE)	18
17. USER'S NOTES	20

Please pay particular attention to the text marked with this sign.

The manufacturer reserves the right to make changes to the design and the software of the device without any deterioration of the technical parameters (some functions may not be available in older versions).

Table 16.5. Special answer (errors: function field = 0x84 or 0x83 in the case of the READ function and 0x86 in the case of the WRITE function):

Error code (HB-LB in the data field)	Error description
0x0001	non-existing register address
0x0002	wrong write register value
0x0003	improper function number

Example 16.5. Error frame for a non-existing read register address:

0x01 - 0x84 - 0x02 - 0x0001 -0x5130

Table 16.6. Map of registers for the MODBUS-RTU protocol

Register address HEX (DEC)	Value (HEX or DEC)	Description of register and access type (R- read only register, R/W - read and write register)		
0x00 (0)	0	not used or reserved		R
0x01 (1)	540	device type identifier		R
0x02 (2)	10 ÷ 99	display software (firmware) ve	rsion	R
0x03 ÷ 0x05	0	not used or reserved		R
0x06 (6)	0 ÷ 7	current status of outputs 1, 2: on	bits 0, 1, bit=1 means the output is switched	R
0x07 (7)	0 ÷ 20000	current state of the analogue of	output (0 ÷ 20,000 μA or 0 ÷ 10,000 mV)	R
0x08 (8)	-100 ÷ 700	thermocouple cold tip temper	rature (resolution 0.1 $^{\circ}$ C)	R
0x09 ÷ 0x0D	1000 + 10000	measured values (input 1, inpu	ut 2, difference 1-2, sum 1+2, average)	R
0x09 ÷ 0x0A	-1999 - 19999	values to be displayed for rem	ote inputs (when parameters nP = Ffia) (1)	R/W
0x0E ÷ 0x0F	0	not used or reserved		R
0x10 ÷ 0x11	-1999 ÷ 19999	minimum values of the measu and 2)	rement channels of the display (channel 1	R
0x12 ÷ 0x13	-1999 ÷ 19999	maximum values of the measu and 2)	rement channels of the display (channel 1	R
0x14 ÷ 0x17	0	not used or reserved		R
0x18 (24)	0 ÷ 6	day of the week in the internal	RTC clock (counted based on the date)	R
0x19 (25)	0x0101 ÷ 0x630C	years (HB) and months (LB)		R/W
0x1A(26)	0x0100 ÷ 0x1F17	days (HB) and hours (LB)	internal real time clock (BTC) (1)	R/W
0x1B (27)	0x0000 ÷ 0x3B3B	minutes (HB) and seconds (LB)		R/W
Configuration pa	rameters (chapter 10)			
0x1C (28)	0 ÷ 5	parameter 0: d 15 I value to be	displayed for the 1st channel	R/W
0x1D (29)	0 ÷ 5	parameter 1: 5 value to be	displayed for the 2nd channel	R/W
0x1E (30)	0 ÷ 1	parameter 2: d (53) a real time	clock (as the 3rd channel)	R/W
0x1F (31)	3 ÷ 30	parameter 3: dPEr display cha	nnels switching period	R/W
0x20 (32)	0 ÷ 3	parameter 4: cold the color of	the display for the 1st channel	R/W
0x21 (33)	0 ÷ 3	parameter 5: cold the color of	the display for the 2nd channel	R/W
0x22 (34)	0 ÷ 3	parameter 6: Col. 3 the color of	the display for the clock (RTC)	R/W
0x23 (35)	0 ÷ 4	parameter 7: Real the color of	f the display for alarms	R/W
0x24 (36)	0 ÷ 3	parameter 8: L c of the color of	f the LED indicators	R/W
0x25 (37)	1 ÷ 3	parameter 9: 👉 🐻 the brightn	ess of the display	R/W
Configuration par	ameters for the measure	ment channel numbered KP = 0) ÷ 1 (0=channel 1, 1=channel 2)	
0x26 (38) +KP*7	0 ÷ 17	parameter 10+KP*7:	of measurement input (chapter 10)	R/W
0x27 (39) +KP*7	1 ÷ 10	parameter 11+KP*7: 🛃 digit	al filtration of measurements (response time)	R/W
0x28 (40) +KP*7	0÷3	parameter 12+KP*7: dol posit	ion of the point or resolution for temperature	R/W

15. RS485 COMMUNICATION INTERFACE (acc. to EIA RS-485)

The installation specification for the RS485 interface is the following:

- maximum cable length - 1 km (observe the installation guidelines, chapter 2, sub-items b, c, and d)

- maximum number of devices in a RS485 line - 30, in order to increase the number, use RS485/RS485 amplifiers - termination and polarizing resistors when the MASTER is at the start of the line (Fig. 15):

- at the start of the line $-2 \times 820 \Omega$ to the ground and +5 V of the MASTER and 150Ω between lines

- at the end of the line -150Ω between lines

- termination and polarizing resistors when the MASTER is in the centre of the line:

- at the converter $2 \times 820 \Omega$, to the ground and +5 V of the converter
- at both ends of the line 150 Ω each between lines

Equipment from different manufacturers that form the RS485 network (e.g. RS485 converters/USB) may have integrated polarizing and terminating resistors; in such a case there is no need to use external elements.



Fig. 15. Pictorial diagram of the RS485 network

16. MODBUS-RTU SERIAL TRANSMISSION PROTOCOL (SLAVE)

Character format :8 bits, 1 stop bit, no parity bit Available functions :READ - 3 or 4, WRITE - 6

Table 16.1. Claim frame format for the READ function (frame length - 8 bytes):

address of the device	function 4 or 3	read register address: 0 ÷ 75 (0x004B)	number of read registers: 1 ÷ 76 (0x004C)	CRC check sum
1 byte	1 byte	2 bytes (HB-LB)	2 bytes (HB-LB)	2 bytes (LB-HB)

Example 16.1. Reading of a register with address 0: 0x01 - 0x04 - 0x0000 - 0x0001 - 0x31CA

Table 16.2. Claim frame format for the WRITE function (frame length - 8 bytes):

address of the device	function 6	write register address: 0 ÷ 75 (0x004B)	write register value	CRC check sum
1 byte	1 byte	2 bytes (HB-LB)	2 bytes (HB-LB)	2 bytes (LB-HB)

Example 16.2. Entry in a register with address 10 (0xA) with the 0 value: 0x01 - 0x06 - 0x000A - 0x0000 - 0xA9C8

Table 16.3. Response frame format for the READ function (minimum frame length - 7 bytes):

address of the device	function 4 or 3	number of bytes in the data field (max. 76*2=152 bytes)	data field - register value	CRC check sum
1 byte	1 byte	1 byte	2 ÷ 140 bytes (HB-LB)	2 bytes (LB-HB)

Example 16.3. Response frame for register value equal to 0: 0x01 - 0x04 - 0x02 - 0x0000 - 0xB930

Table 16.4. Response frame format for the WRITE function (frame length - 8 bytes):

copy of the claim frame for the WRITE function (Table 16.2)

1. SAFETY PRINCIPLES



in order to avoid electrocution or damage to the device, its mechanical and electrical installation must be performed by qualified workers

before switching on the power supply, make sure that all cables and wires are properly connected

before making any modifications to the wire and cable connections, switch off the voltage supplied to the device

ensure proper operating conditions compliant with the technical specification of the device (chapter 5, power supply voltage, humidity, temperature)

2. INSTALLATION GUIDELINES

The device is designed so as to ensure an appropriate level of immunity to most interferences that may occur in industrial environments. In environments of unknown level of interferences, it is recommended to implement the following measures so as to prevent potential interference with the operation of the device:

a) do not supply the device from the same lines as high-power equipment without using appropriate power line filters

b) use shielded supply, sensor, and signal cables, whereby the earthing of the shield should be single-point and located as close to the device as possible

c) avoid running measurement (signal) cables in the direct vicinity of and parallel to power and supply cablesd) it is recommended to use twisted pair signal cables

e) avoid proximity of remotely controlled devices, electromagnetic meters, high power loads, loads with phase or group power control, and other devices that cause high impulse disturbances

f) ground or zero metal rails on which rail-mounted devices are installed

Make sure to remove the protective film from the LED display before the first use of the device.

3. GENERAL CHARACTERISTICS OF THE DISPLAY

■ monitoring of temperature and other physical values (humidity, pressure, level, speed, etc.) processed to a standard electrical signal (0/4÷20mA, 0÷10V, 0÷60mV, 0÷2.5kΩ)

2 universal measurement inputs (thermoresistance, thermocouple, and analog) with additional functions:
 mathematical (difference, total, and average values of measurements from two inputs)
 with minimum and maximum memory of the measured value

- with remote display of data (via the RS485 interface, MODBUS-RTU protocol, slave)

- real time clock shown alternately with measured values
- programmable 4 colors for the measurement channels show, the clock, the LED indicators and the alarms
- 2 independent alarm outputs of the on/off type (ON-OFF, heating, cooling, relative alarms, manual mode)
- alarm signaling with diode indicators and with programmable color of the display
- BIN digital input to change the operation mode:
 - start/stop for outputs
 - manual/automatic mode for outputs
 - stepwise change of the preset value (day/night) for alarms
 - stop of display indications for the measurements (HOLD function)
 - change or stop of switching of channels to be displayed
 - keypad block
 - unconditional preview of values measured from the inputs (when mathematical functions are displayed)
- analog output 0/4÷20mA or 0/2÷10V (alarm, retransmission)
- possibility to convert the input signals into the analog output standard in the retransmission mode;

selection of the value controlling the operation of each output (any input, subtraction, addition, average of measurements)

manual mode (open control loop) available for binary outputs and the analog output, which makes it possible to set the value of the output signal in the range of 0-100%; possibility of self-activation in the event of sensor failure

- an integrated 24 V DC power supply supplying the field transducers
- RS485 serial interface (galvanically isolated, MODBUS-RTU protocol, SLAVE)
- compensation of line resistance for resistance sensors and of temperature of cold thermocouple tips

programmable values be displayed (measurements, mathematical functions or remote), types of inputs,

indication ranges (for analogue inputs), alarm, communication, access and display options and other parameters

- possibility to protect access to the configuration parameters with a user password
- parameter configuration methods:
- from the film keypad located on the front panel of the device

- through the RS485 or the AR956 (AR955) programmer and the free ARSOFT-CFG-WZ1 software (Windows Vista/7/8/10) or a user's application, MODBUS-RTU communication protocols

■ software and the AR956 (or AR955) programmer that enables viewing measured values and quick configuration of single or ready sets of parameters that were saved earlier on the computer for future use, e.g. in other devices of the same type (copying of configuration);

- AR540 an industrial housing made of polycarbonate 222x146x55, protection rating IP65
- - AR753 wall mounted housing made of aluminum 500x166x35, protection rating IP51

options to be selected (in the ordering method): 24 V AC/DC power supply, SSR alarm outputs, 0/2-10 V analogue output

- high accuracy, long-term stability, and immunity to interferences
- available accessories:
 - AR956 or AR955 programmer
- RS485/USB converter



Before you start working with the recorder, make sure to become familiar with this operating instruction and perform proper electrical and mechanical installation, as well as configuration of the parameters.

4. CONTENTS OF THE SET

- display
- user instruction
- warranty card

5. TECHNICAL DATA

2 universal inputs (set with parameters of 1, of 2)	measurement range
- Pt100 (RTD, 3- or 2-wire)	-200 ÷ 850 °C
- Ni100 (RTD, 3- or 2-wire)	-50 ÷ 170 °C
- Pt500 (RTD, 3- or 2-wire)	-200 ÷ 620 °C
- Pt1000 (RTD, 3- or 2-wire)	-200 ÷ 520 °C
- thermocouple J (Fe-CuNi)	-40 ÷ 800 °C
- thermocouple K (NiCr-NiAl)	-40 ÷ 1,200 °C
- thermocouple S (PtRh 10-Pt)	-40 ÷ 1,600 °C
- thermocouple B (PtRh30PtRh6)	300 ÷ 1,800 °C
- thermocouple R (PtRh13-Pt)	-40 ÷ 1,600 °C
- thermocouple T (Cu-CuNi)	-25 ÷ 350 °C
- thermocouple E (NiCr-CuNi)	-25 ÷ 820 °C
- thermocouple N (NiCrSi-NiSi)	-35 ÷ 1,300 °C
- current ($R_{in} = 50 \Omega$)	0/4 ÷ 20 mA
- voltage ($R_{we} = 33 \text{ k}\Omega$)	0 ÷ 10 V

hRnd/hoFF	unconditional manual mode on/off, chapter 9.1
inof / inPu	unconditional view of the measured values from inputs 1 and 2, chapter 9.1
hoch/nEch	stop/change of the channel to be displayed, chapter 9.1
hdoF/hold	stop of display indications for the measurements (HOLD function), chapter 9.1
SRUE	saving of factory parameter values (chapter 10)

14. CONNECTING THE CONTROLLER TO A COMPUTER AND AVAILABLE SOFTWARE

It may be useful (or necessary) to connect the display to a computer in the following situations: - remote monitoring and recording of current measurement data and process (status of the outputs) control; - quick configuration of parameters, to include copying of settings to other displays of the same type In order to establish communication over long distances, it is necessary to establish a connection in the RS485 standard with an available port in the computer (directly or using an RS485 converter), as described in chapter 15. Moreover, as a standard, the displays are equipped with PRG port which enables connecting to a computer using AR956/955 programmer (without galvanic separation, cable length approx. 1.2 m). Both the programmer and the RS485 converter require installation of the supplied serial port drivers on the computer. Communication with devices is effected using a protocol compatible with MODBUS-RTU (chapter 16). The following applications are available (on a CD delivered with the AR956/955 programmer or to be downloaded from the Internet at *www.apar.pl*, *Download section*, for operating systems Windows Vista/7/8/10):

Name	Software description
ARSOFT-CFG- WZ1 (free)	 display of current measurement data from the connected device configuration of the type of measurement input, the indication range, the alarm options, the display, the communication, etc. (chapter 10) creation on the disk of a "cfg" file with the current configuration of the parameters for future use (copying of configuration) the software requires communication with the display via the RS485 or PRG port (AR956/955)
ARSOFT-WZ2 (payable)	 display and recording of current measurement data from a maximum of 30 channels (only from devices made by APAR) the software requires communication with the display via the RS485 or PRG port (AR956/955)

The detailed descriptions of the aforementioned applications can be found in the installation folders.

NOTE:

Before establishing the connection, make sure that the MODBUS address of the device (parameter 45: Heter) and the speed of transmission (46:) are the same as the settings of the software. Moreover, in the software options, set the number of the COM serial port in use (in the case of the RS485 converter or the AR956/955 programmer, this is the number assigned by the operating system during installation of the drivers).

12.3. ANALOG OUTPUT

The standard of the output signal is determined by parameter 35: **Here** (chapter 10, Table 10). The analogue output can work in one of the following modes: retransmission of measurement (parameter 36: **out** R = RET), manual mode (36: **out** R = RET) and as an automatic control output (36: **fund**) = **out** R).

In the mode of retransmission of a selected measurement (34: -5) the output signal is proportional to the signal measured in the range set by parameters 37: -5 and 38: -5 (e.g. 0 mA for the measured value 0 °C when

 $B = L_0 = 0 °C$, 20 mA for 100 °C when $B = H_0 = 100 °C$ and, as appropriate, 10 mA for the half of the range, i.e. 50 °C). Manual operation (chapter 12.4) enables smooth change of the output signal in the range of 0-100% with an increment of 1% and the initial value equal to the last value in the automatic mode (measurement retransmission or alarm mode).

In the alarm output mode, the alarm parameters and their functions are identical as in the case of output 1 (the applicable parameters are 24: **COST**, 25: **FLO**, 26: **FUN**, 27: **SEE**, 28: **HD**). In the alarm mode (type ON-OFF with hysteresis), the output assumes limit values (lower or upper value, e.g. 0mA or 20mA) without the intermediate values, which may be used to switch on, e.g. the SSR relay.

12.4. MANUAL AND REMOTE CONTROL FUNCTION

The manual mode enables setting the value of the output signal in the entire range of its variability (0-100%), thus enabling operation in an open regulation loop (no automatic coupling between the measured value and the output signal). Manual operation is available individually for each output of the device and is programmed using parameters 26: Fun 1, 31: Fun 2, and 36: Fun 2, chapter 10, Table 10. Also, outputs can be configured for quick (unconditional) manual mode controlled by:

- the BIN binary input, by programming as appropriate parameter 39: Func (chapter 9.1),

- measurement error of the sensor (range exceeded or a defect), when 25: FEB2, or 30: FEB3 is equal to FEB3 In the case of bi-state outputs (1, 2), the change of the output signal consists in setting the filling coefficient (using

parameter 41: IFFE) with impulse period defined by parameter 40: Ea . The preset value of the manual mode 41:

ESE = 0 stands for a permanently switched off output; value 100 stands for a permanently switched on output. The value can be set directly using the **[UP]** or **[DOWN]** button (only in the case of output 1, chapter 12.1) or using the quick menu (chapter 11) or alternatively in the parameter configuration mode (from the film keypad or remotely using the serial RS485 or PRG port, chapters 10, 14-16).

13. MESSAGE AND ERROR SIGNALING

a) measurement errors:

Code	Possible causes of error
	 the measurement range of the sensor is exceeded from the top () or from the bottom (). the sensor is broken the sensor that is connected is different than the one that is set in the configuration (chapter 10, parameter 10; mPH or 17; mPH)

b) temporary messages and errors (one-time and recurring):

Code	Description of message	
EodE	mode of entering the password for access to the configuration parameters, chapter 10	
Err	the password is invalid,	
EonF	the parameter configuration menu was accessed,	
SER-/SEOP	control start/stop, chapter 9.1	
5EE 1/5EE2	change of the preset value (day/night) for output 1, chapter 9.1	
bLoc / boFF	keypad block on/off, chapter 9.1	

- voltage ($R_{in} > 2 M \Omega$)		0 ÷ 60 mV
- resistance (3- or 2-wire)		0 ÷ 2,500 Ω
- remote data display (through RS485 or PRG port)		-1999÷ 9999
Response time (10 ÷ 90%)		$0.5 \div 4 \text{ s}$ (programmable with parameters F $(1, F)$ (F $(1, 2)$)
Resistance of leads (R	ΓD, Ω)	$R_d < 25 \Omega$ (for each line)
Resistance input curre	ent (RTD, Ω)	400 μA (Pt100, Ni100), 200 μA (others)
Processing errors (at a	mbient temperature of 25 °C):	-
- basic	- for RTD, mA, V, mV, Ω	0.1% of the measurement range ± 1 digit
	- for thermocouples	0.2% of the measurement range ± 1 digit
- additional for thermo	couples	<2 °C (temperature of cold tips)
- additional from ambie	ent temperature changes	< 0.003% of the input range /°C
Resolution of measure	ed temperature	programmable, 0.1 °C or 1 °C
Range of indications	(resolution of analog inputs)	-1999 ÷ 9999, programmable
Position of the decin	nal point for analog inputs	programmable, 0 ÷ 0.000
Binary input BIN (cor	ntact or voltage <24 V)	bistable, active level: short circuit or <0.8 V
Communication	- RS485 (galvanically isolated)	- speed 2.4-57.6 kb/s,
interfaces	- PRG programming connection (no isolation), standard	format 8N1 (8 data bits, 1 stop bit, no parity bit) - MODBUS-RTU protocol (SLAVE)
(RS485 and PRG, do not use at the same time)		
Bi-state outputs (2-relays or SSR)	- relay (P1, P2), standard	5A / 250 VAC (for resistance loads), 1 main (SPDT-NO), 1 additional (SPST-NO)
	- SSR (SSR1, SSR2), option	transistor type NPN OC, 24 V, internal resistance 850 Ω
Analogue output	- current 0/4 ÷ 20 mA (standard)	maximum resolution 1.4 µA (14 bit)
(1 current or voltage)		load capacity of the output Ro < 1,000 Ω
(i current or voltage)	- voltage 0/2 ÷ 10 V (option)	maximum resolution 0.7 mV (14 bit)
		load capacity of the output lo < 3.7 mA (Ro > 2.7 k Ω)
	- output basic error	< 0.1% of the output range
7-segment LED displa (4 digits, with adjustme	y nt of control and brightness)	AR540 - 57 mm, AR751 - 57 mm, AR753 - 100 mm, 4 colors (red, orange, yellow, green)
Signaling	- relay active - number of channel shown	LED diodes, 4 colors (the same as for the display)
	- messages and errors	LED display
Power supply (Usup)	- 230 VAC (standard)	85-260 VAC/5VA
	- 24 VAC/DC (option)	20-50 VAC/ 5 VA, 22-72 VDC/ 5 W
Power supply of field transmitters		24 VDC / 50 mA
Rated operating conditions		0-50 °C, <100% RH (non-condesing)
Operating environment		air and neutral gases
Enclosure protection rating and mounting method		AR540 - IP65, industrial enclosure, wall-mounted AR753, AR751 - IP51, aluminum enclosure
Weight		AR540 - 800 g, AR751 - 1,100 g, AR753 - 2,300 g
Electromagnetic compatibility (EMC)		immunity: according to the PN-EN 61000-6-2
		emissivity: according to the PN-EN 61000-6-4

6. ENCLOSURE DIMENSIONS AND INSTALLATION DATA · · - - · ·

a) general data and dimensions of AR540		
Enclosure	industrial IP65, Gainta G218	
type		
Material	polycarbonate	
Dimensions	222 x 146 x 55 mm (W x H x D)	
Fixing methods	4 holes, dia. 4.3 mm, distance 210x116 mm, accessible after the front cover is removed	
Conductor cross- sections	2.5 mm ² (supply and bi-state outputs), 1.5 mm ² (others)	

b) general data and dimensions of AR751

. ..

. .

Enclosure	wall-mounted IP51, DELTA-BOX	
type		
Material	aluminum	
Dimensions	300 x 106 x 50 mm (W x H x D)	
Fixing methods	in horizontal guide rails on the back of the enclosure (e.g. with M4 or M5 screws into nuts inserted into the guide rails)	
Conductor cross- section	2.5 mm ² (supply and bi-state outputs), 1.5 mm ² (others)	

c) general data and dimensions of AR753

Enclosure type	wall-mounted IP51, DELTA-BOX	
Material	aluminum	
Dimensions	500 x 166 x 35 mm (W x H x D)	
Fixing methods	in horizontal guide rails on the back of the enclosure (e.g. with M4 or M5 screws into nuts inserted into the guide rails)	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
Conductor cross- sections	2.5 mm ² (supply and bi-state outputs), 1.5 mm ² (others)	k_52.pl k

222

町 Ë 目

d) AR540 - installation of the cabling

- isolate the power supply before making any changes to the cabling

- remove 6 screws in the front cover and take it off the device

- the electric cables must be inserted into the enclosure through cable glands

- in order to achieve the IP65 rating, the nuts of the cable glands and the enclosure cover must be tightened precisely

e) AR751 and AR753- installation of the cabling

- isolate the power supply before making any changes to the cabling

- unscrew the screws fastening the left side of the enclosure (the one with the keyboard) and move it away from the enclosure

- in order to gain access to the connections, slide the front panel (Plexiglas) to the left out of the guide rail

- in order to make installation easier, the printed circuit board with the connections can also be moved a few centimeters to the left

- the electric cables must be inserted into the enclosure through cable glands

- the power supply should be provided through the upper gland; the earthing/zero wire (most often yellow-green) should be connected to the protective terminal (PE)

12.2. TYPES OF OUTPUT CHARACTERISTICS

The type of operation of each output is programmed using parameters 26: Fun 1 and 31: Fun 3, chapter 10, Table 10.

a) basic operating characteristics of outputs





block SEE 7, SEE2	SEE2, both = simultaneous block of changes to parameters 27: SEE and 32: SEE2		
43: 2855 password	 ÷ 5555	password for the parameter configuration menu	
44: PPro protection of the configuration with a	oFF	entry into the configuration menu is not password- protected	an
password	on	entry into the configuration menu is password-protected	
COMMUNICATION OPTIONS AND SETING OF THE REAL TIME CLOCK- submenu			
45: Rode MODBUS-RTU address	1 ÷ 247	individual address of the device in the RS485 network (chapter 16)	1
46: F communication speed for RS485 and the PRG connection	24 kbit/s, 18 kbit/s, 26 kbit/s, 192 kbit/s, 234 kbit/s, 575 kbit/s		197 kbit/s
47:	setting the time of the clock (RTC) in the hh:mm format		current

Notes: (1) – for $\mathbf{I}_{\mathbf{I}} = \mathbf{I}$ the response time is equal to 0.5 s, for $\mathbf{I}_{\mathbf{I}} = \mathbf{I}_{\mathbf{I}}$ it is equal to at least 4 s.

Higher degree of filtration means a "smoother" measured value and a longer response time, which is recommended in the case turbulent measurements (e.g. water temperature in the boiler).

(2) – applies to analog inputs (mA, V, mV, Ω)

(3) - the parameter also defines the state of the output outside of the measurement range

11. QUICK ACCESS MENU

In the measurement mode (when the measured values are displayed), it is possible to immediately access certain configuration parameters and functions without the need to enter a password. This possibility is offered by the quick menu, which can be accessed by pressing the **[SET]** button. The parameter is selected and edited in the same way as described above (in chapter 10).

Table 11. Complete list of elements accessible in the quick configuration menu.

Element	Description
SEE 1	preset value 1 (parameter 27: SEE I), optional element - unavailable when parameter 26: Fund = hRnd , changes blocked at the time of change of the preset value 1 to SEEC (chapter 9.1)
5662	preset value 2 (32: 5552), optional element - unavailable when parameter 31: 5072 = off or hand
HSEE	preset value of the manual mode (41: KEEE), optional element - available for outputs in the manual operation mode

12. OUTPUTS CONFIGURATION

The programmable architecture of the display enables using it in many fields and applications. Before the operation of the device starts, it is necessary to set the parameters according to specific requirements (chapter 10). A detailed description of configuration of the operation of outputs is given in chapters 12.1÷ 12.4. The default (factory) configuration is the following: outputs 1 is related to input 1 and output 2 is related to input 2, control mode ON/OFF with hysteresis, output 3 and the analog outputs are switched off (Table 10, *Factory settings* column).

12.1. CHANGING THE OUTPUT SET VALUES

The simplest way to change the preset value for output 1 (parameter 27: **SEE**) or 41: **MSEE** when output 1 is in the manual mode) is to use the **[UP]** button or the **[DOWN]** button. In the case of the other outputs, the quick menu can be used (chapter 11). As an alternative, it is possible to change the preset value in the parameter configuration mode (using the methods described in chapter 10).

7. DESCRIPTION OF TERMINAL STRIPS AND ELECTRICAL CONNECTIONS

The wire terminals are accessible after the front cover has been removed; see chapter 6. Table 7. Numbering and description of terminal strips

Terminals	Description
IN1- IN2- IN3	input Pt100, Ni100, Pt500, Pt1000, resistance, (2- and 3-wire)
IN2-IN3	thermocouple input TC (J, K, S, B, R, T, E, N) and voltage input 0÷60 mV
IN3- GND (9)	current input 0/4÷20 mA
IN4- GND (9)	voltage input 0÷10 V
10	output +24 V (in relation to 9-GND) of the integrated power supply of field transducers
11- GND (9)	analogue current output (0/4-20 mA) or voltage output (0/2-10 V)
0 - GND (9)	binary input BIN (contact or voltage <24 V)
PRG	programming connection for cooperation with the programmer (only AR956 or AR955)
12-13	RS485 serial interface (MODBUS-RTU transmission protocol)
22-23	power supply input 230 VAC or 24 VAC/DC
14-15	relay output P1 or SSR1
17-18	relay output P2 or SSR2
PE	protective terminal

a.1) **AR540** - numbering of connections and method of connecting sensors and measurement signals (described in Table 7)



a.2) **AR751**, **AR753** - numbering of connections and method of connecting sensors and measurement signals (described in Table 7)



NOTE:

- AR751 and AR753 have metal enclosure which must be earthed/zeroed by connecting earthing/zero wire (most often yellow-green) to the protective terminal (PE) (inside the enclosure next to the upper gland). - For connecting the device to a computer through the PRG socket, use only the AR956/955 programmer,

a connection made with a regular USB cable may cause damage to the equipment. In the AR540, the programming connection is accessible after the front panel has been removed; in the AR751 and AR753, the programming connection is accessible after the plug is unscrewed in the left side (next to the keyboard).

b) connection of a 2- and 3-wire transducer (lout - output current, Uout - output voltage)

+24V IN4 IN2	+24V GND IN4 IN3 IN12	+24V GND IN4 IN3 IN2 IN1
lout +24V	lout 24V	Uout 24V
2-wire	3-wire	3-wire
transducer	transducer	transducer

8. IMPORTANT COMMENTS PERTAINING TO OPERATION - use of fire suppression systems

If an induction load is connected to the transmitter's contacts (e.g. a contactor coil or a transformer), when the contacts open up there are frequent overvoltages and electrical arcs caused by the discharge of the energy gathered in the induction. The particularly negative consequences of such overvoltages include reduced service life of contactors and transmitters, damage to semiconductors (diodes, thyristors, and triacs), damage to or interference with the control and measurement systems and emission of electromagnetic field that interferes with local devices. In order to avoid such consequences overvoltages must be reduced to a safe level. The simplest method is to connect an appropriate suppression module **directly** to the terminals of the inductive load. Generally speaking, appropriate types of suppression circuits must be selected for each type of inductive load. Modern contactors are generally fitted with appropriate factory-made suppression circuits. If such circuits are lacking, a contactor with an integrated suppression system must be purchased. Temporarily, the load can be shunted with RC system, e.g. R=47 $\Omega/1$ W and C=22 nF/630 V. The fire suppression circuit must be connected to the inductive load terminals. The use of suppression circuit limits Douve burning of relay contacts in controller and reduces likelihood of their sticking.

Supply

9. FUNCTIONS OF BUTTONS AND LED INDICATORS. MINIMUM AND MAXIMUM VIEW



a) button functions in measurement display mode

Button	Description [and marking in contents of the instructions]
lub	[UP] or [DOWN] : changes the preset value for output 1 (parameter 27: 551) when output 1 works as an alarm, or 41: 1555 when output 1 in the manual mode, chapters 10 and 12.4)
SET	[SET] : - input in the quick access menu (chapter 11) when outputs 1 or 2 are active
▲ + ▼	[UP] and [DOWN] (at the same time): input in the parameter configuration menu (after hold time longer than 1 s). If parameter 44: Para = ba (password protection is activated) enter the access code (chapter 10)
SET +	[SET] and [UP] : - displays the saved MAXIMUM VALUE of the measurement of the current channel - deletes the maximum value of the measurement (after hold time > 6 s)
SET + 🔻	[SET] and [DOWN] : - displays the saved MINIMUM VALUE of the measurement of the current channel - deletes the minimum value of the measurement (after hold time > 6 s)
[UP], [DOWN], [SET]	when any button is pressed, the channels of the display are switched

30: Feat failure status of output 2 (3)	(signal): not = no change, off = switched off, on = switched on, non = manual mode with set output signal level (parameter 26: MSEE , chapter 12.4)			
31: Funz function of output 2 (chapter 12.2)	DFF = off, hRnd = manual mode, incl = heating, dir = cooling, bRon or bRnd = band 2* SEE2 (SEE3 for output 3) around SEE 1, dEne or dEnn = deviation from SEE 1			
32: SEE preset value 2	applies to outp (only when 22	applies to output 2, changes in scope 13: Lo2 ÷ 14: H 2 or 6: Lo1 ÷ 7: H 1 (only when 22: Lo52 = InP 1)		
33: 12 hysteresis of output 2	••• ••••• ••••••••••••••••••••••••••••			
ANALOG OUTPUT CONFIG	URATION – sub	menu ወታደቭ - (chapter 12.3)		
34: CDSF control signal for the analogue output assigned inputs)	nP 1 = measu <u>Subt</u> = differen measurements measurements	rement from input 1, TAPE = measurement from input 2, nce between measurements (1-2), Rdd T = sum of s (1+2), Rur T = average value of measurements (sum of s from two inputs divided by 2)	inP 1	
35: RESP type of analog output	depending on voltage outpu	the order code: for current output 원 20 or 북 20 mA, for t 원 10 or 2 10 V	0-20 mA (0-10 V)	
36: Fund function of analogue output	oFF = off, har	I = manual mode, FET = retransmission of measurement, output, a detailed description is provided in chapter 12.3	oFF	
37: A-Lo lower indication for retransmission	start of the our parameter is a FEFT)	start of the output scale - for output signal value 0/4 mA or 0/2 V (the parameter is active only for measurement retransmission when 36: FunR =		
38: R-H upper indication for retransmission	end of the out parameter is a FEFT)	end of the output scale - for output signal value 20 mA or 10 V (the parameter is active only for measurement retransmission when 36: Funk =		
CONFIGURATION OF THE E	BINARY INPUT E	SIN AND THE MANUAL MODE – submenu b inH		
	nonE	the BIN input is inactive		
	5552	change of the preset value (day/night) for output 1		
	bloc	keypad block		
39: Func	h8n 1	unconditional manual mode for output 1 (P1/SSR1)		
binary input BIN function	hAn2	unconditional manual mode for output 2 (P2/SSR2)		
	h8n8	unconditional manual mode for the analogue output	nonE	
BIN	5152	control start/stop (applies to all outputs)		
	in ^p u	unconditional view of the measured values from inputs 1 and 2		
	honE	stop/change of the channel to be displayed		
	hold	stop of indications for the measurements (HOLD function)		
40: E impulse period	5 ÷ 55 s	period of switching of the status of outputs 1 and 2 in the manual mode	🖬 s	
41: HSEE preset value of the manual mode	• ÷ • • % 1% step	control value for outputs in the manual mode, applies to all outputs (1, 2, and the analogue output), chapter 12.4	500 %	
ACCESS OPTIONS – subme	nu AccE			
42: 55E value change	bFF = no blocks, 5EE 1 = block of parameter 27:5EE 1, 5EE 2 = block 25:			

	tern	thermoelectric sensor (thermocouple) type N (-35÷ 1,300°C)	
	4-20	current signal 4 ÷ 20 mA	
	0-20	current signal 0 ÷ 20 mA	
	0-10	voltage signal 0 ÷ 10 V	
	0-60	voltage signal 0 ÷ 60 mV	
	FE5	resistance signal 0 ÷ 2,500 Ω	
	r ERo	remote input from the RS485 or PRG port, chapter 16, Table 16.6	
11: F L I (18: F L 2) filtration (1)	8÷20	digital filtration of measurements (response time)	ч
	Ð	no point (2) or 1°C for temperature	
	1	🖽 (2) or resolution 0.1 °C for temperature	8
position of the	8	ffff (2)	(0.1 °C)
point/resolution	E	ffff (2)	
13: Lo I (20: Lo) lower limit	-19919 ÷ 1800	lower setting limit for the preset value 20: SEE or 25: SEE	
or bottom of the indication range (2)	4999 ÷ 9999	indication 0/4 mA, 0 V, 0 Ω - start of the input scale $({\bf 2})$	-999 °C
14: HT (21: HT) upper	4999 ÷ 1800	upper setting limit for the preset value 20: 5655 or 25:	
indication range	4999 ÷ 9999	indication for 20 mA, 10 V, 60 mV, 2.5 k Ω - end of the input scale (2)	
15: cRo (22: cRo () calibration of the zero	zero offset for	measurements: 500 ÷ 500 °C or 500 ÷ 500 units (2)	Ĵ. €
16: - AL I (23: - AL I) gain	850÷ 8650 %	calibration of inclination (sensitivity) for measurements	111 %
MAIN OUTPUT CONFIGUR	ATION (P1/SSR1)) – submenu 💵 🖥 - chapter 12 (12.2)	
24: co51 control signal for output 1 (assignment of input)	measurements	rement from input 1, TAP2 = measurement from input 2, nce between measurements (1-2), Idda = sum of 5 (1+2), For 3 = average value of measurements (sum of 5 from two inputs divided by 2)	inP (
25: FECH failure status of output 1 (3)	output status i (signal): hoch manual mode 12.4)	n the case of lack of or damage to the measurement sensor = no change, DFF = switched off, Dn = switched on, hAnd = with set output signal level (parameter 26: HSEE , chapter	no[h
26: Fun I function of output 1	oFF = off, hAn	e manual mode, است = heating, ط اله = cooling	oFF
27: SEE preset value 1	applies to outp (only when 17:	out 1, changes in scope 6: Lo 원 ÷ 7: 버너 or 13: Lo2 ÷ 14: 버고 co5 l = 디아2)	999 € °C
28: He hysteresis of output 1 or PID tuning zone	hysteresis or in	sensitivity zone of PID tuning in mode Futo , chapter 12.5 or 🗗 ÷ 📴 units (2)	Se ∰
CONFIGURATION OF THE A	UXILIARY OUT	PUT (P2/SSR2) – submenu out 1 - chapter 12	
29: co51 control signal for output 2 (assignment of input)	Implie = measurement from input 1, Implie = measurement from input 2, Suble = difference between measurements (1-2), Rdd = sum of measurements (1+2), Rdd = average value of measurements (sum of measurements from two inputs divided by 2)		inP (

b) button functions in the parameter configuration menu and the quick access menu (chapters 10 and 11)

Button	Description [and marking in the contents of the instructions]
SET	[SET] : - selects the item displayed in the configuration menu (entering a lower level) - edits the current parameter (the value blinks on the display) - approves and saves the edited parameter value
lub V	[UP] or [DOWN]: - moves to the next or previous parameter (submenu) - changes the value of the edited parameter
▲ + ▼	 [UP] and [DOWN] (simultaneously): returns to the previous menu (higher level) cancel changes to the edited value (the blinking stops) returns to the measurement display mode (only [UP] and [DOWN] after hold time >0.5 s)

c) functions of the LED signaling indicators

Diode [marking]		Description
1 2	[A1] [A2]	ALARM: signals switching on of outputs P1/SSR1 and P2/SSR2
1 2	[K1] [K2]	CHANNEL : signals the number of the currently shown channel of the display (when the clock is displayed, both indicators are off)

9.1. BINARY INPUT

F

Binary input **BIN** performs a function that is programmable with parameter 39: Func (chapter 10). The **BIN** input works with the bi-stable signal i.e. the supplied signal (voltage or switch) must be permanent (on/off type). Activation or deactivation of the function is indicated by appropriate messages on the lower display (described below). The **BIN** input is in the active state for a short circuit or a voltage <0.8 V.

Table 9.1. Available **BIN** input functions

Source	Description (scription (depending on the value of parameter 39: Fune)			
	Func = nonE	the BIN input is inactive (factory setting)	-		
	Func = 5822	discrete change of set value for P1/SSR1 output (day = parameter 27: 5EE : /night = 32: 5EE : , Table 10)	5EE 1/5EE2		
	Func = bLoc	= BLOC keypad block			
	Func = hAn 1	unconditional manual mode for the P1/SSR1 output (chapter 12.4)	hRnd / hoFF		
	Func = hAnd	unconditional manual mode for the P2/SSR2 output	hAnd/hoFF		
	Func = hAnA	unconditional manual mode for the analogue output	hAnd/hoFF		
	Func = 5E5P	start/stop for alarms (applies to all outputs)	SERr / SEOP		
	Func = inPu	unconditional view of the measured values from inputs 1 and 2	inoF / inPu		
	Func = honE	unc = honE stop/change of the channel to be displayed			
	Func = hold	stop of display indications for the measurements (HOLD function)	hdof / hol d		

10. SETTING OF THE CONFIGURATION PARAMETERS

All configuration parameters of the meter are contained in the non-volatile (permanent) internal FLASH memory (data is saved in the memory only when the power supply is being switched off and provided that the settings were changed).

When the device is switched on for the first time, an error message may be shown in the display due to the lack of a sensor or the fact that the sensor that is connected is not one that is factory-programmed. In such an event, the proper sensor or analog signal must be connected and the configuration must be programmed. There are two parameter configuration methods:

1. From the film keypad located on the front panel of the device:

- from the mode where the input measurements are displayed in the configuration menu (press the [UP] and

[DOWN] buttons simultaneously for more than 1 second) If parameter 44: Prot = on (password protection

is on) the display will show the message **CodE**, and then **BDD** with the first digit blinking, use the buttons

- **[UP]** or **[DOWN]** to enter the password (default parameter 43: **PR55** = **PFFF**), to move to successive items and to approve the code, use the **[SET]** button
- after entering the main configuration menu (with the message **ConF**) the display shows a mnemonic name of the submenu (parameter groups: **a 15**² <-> **in 1** <-> **in 2** <-> etc.)
- use the[**UP**] or [**DOWN**] button to move to the relevant submenu and then use the [**SET**] button to approve the selection (the mnemonic name of the parameter is now displayed)
- by pressing the **[UP]** button, you can move to the next parameter, and by pressing the **[DOWN]** button to the previous parameter (e.g. **TOP** <-> **FILE** <-> **dot** <-> etc., the list of the configuration parameters is presented in Table 10)
- to change the value of the current parameter, press briefly the **[SET]** button (the parameter blinks in the edition mode)
- use buttons [UP] or [DOWN] to change the value of the edited parameter
- approve the changed value of the parameter by pressing the [SET] button or cancel it by pressing the [UP] and [DOWN] buttons (briefly press them simultaneously) by pressing the [UP] and [DOWN] buttons again, you will return to the main configuration menu (one level above)
- to exit the configuration: press the [UP] and [DOWN] buttons for a long moment or wait approx. 2 minutes

2. Use the RS485 or the PRG port (AR956/955 programmer) and the ARSOFT-CFG-WZ1 software (chapter 14):

- connect the display to a computer port and start and configure the ARSOFT-CFG-WZ1 application
- after the connection has been established, the current measured value is displayed in the window of the software
- setting and viewing of the device parameters is possible in the parameter configuration window
- new parameter values must be approved with the *Approve changes* button
- the current configuration can be saved in a file or set using values read from a file

NOTE:

- before disconnecting the device from a computer, press the *Disconnect device* button (ARSOFT-CFG-WZ1) in the event of no response:
 - in the *Program options* check the configuration of the port and the *MODBUS Address of the device*
 - make sure that the serial port drivers on the computer have been properly installed for the RS485 converter or the AR956 (AR955) programmer
 - disconnect for a few seconds and then reconnect the RS485 converter or the AR956 (AR955) programmer
 - restart the computer

In the event of indications different from the actual value of the input signal, the zero and the sensitivity of a sensor can be tuned: parameters 15: chool and 22: chool (zero), and 16: chool and 23: chool (sensitivity).

To restore the factory settings, when the power supply is switched on press buttons **[UP]** and **[DOWN]** and hold them until the password menu appears (**Cose**), and then enter the following code **Cose**. As an alternative, a file with default configuration can be used in the ARSOFT-CFG-WZ1 software.

NOTE: /

Do not perform configuration of the device with the keypad and through the serial interface (RS485 or PRG connection) at the same time.

Table 10. List of configuration parameters

Parameter	Range of variability of the parameter and description				
DISPLAY OPTIONS – submenu d .5P					
0: 15 value to be displayed for the 1st channel	mPI = measurement fmeasurement f2), Red I = sum	inP 1			
1: 2 •5 • value to be displayed for the 2nd channel	measurements	oFF			
2: d 53 a real time clock (as	oFF	display of the real time clock (RTC) is switched off			
the 3rd channel)	E ME	display of the real time clock (RTC) is switched on			
3: dPEr display channels switching period	🛾 ÷ 🌆 sec.	single channel display time	🖥 sec.		
4: color of the 1st channel			rEd		
5: color of the 2nd channel	$\mathbf{FEL} = \text{yreen},$ $\mathbf{FEL} = \text{yellow},$ $\mathbf{FER} = \text{orange}$	GrEE			
6: Color of the 3rd channel (RTC)	rEd = red,	HERL			
7: Real alarm color	to parameter 7: 2-01 - the color of the display for the activated alarm, can		colo		
8: Lcol color of the LED diodes	be seen when t	rEd			
9: br 🗗 illumination brightness	8 ÷ 8	level of illumination brightness of the display (\mathbf{E} = 100%)	8		
CONFIGURATION OF MEAS parameters for input 1 (the r below	UREMENT INPU	JTS (submenu on 1 for input 1 and, analogously, one for input 2 ne of the parameter for input 2 are given in the parenthesis) are	2) – the e shown		
	PE	thermoresistance sensor (RTD) Pt100 (-200 ÷ 850 °C)			

	PE	thermoresistance sensor (RTD) Pt100 (-200 ÷ 850 °C)	
	n 1	thermoresistance sensor (RTD) Ni100 (-50 \div 170 °C)	23
	PE5	thermoresistance sensor (RTD) Pt500 (-200 ÷ 620°C)	
	PE 10	thermoresistance sensor (RTD) Pt1000 (-200 ÷ 520°C)	
	tc-J	thermoelectric sensor (thermocouple) type J (-40 \div 800°C)	
10: P (£c=f	thermoelectric sensor (thermocouple) type K (-40 ÷ 1,200°C)	
(17: m²c) type of measurement input	tc-5	thermoelectric sensor (thermocouple) type S (-40 ÷ 1,600°C)	
	tc-b	thermoelectric sensor (thermocouple) type B (-300 ÷ 1,800°C)	
	Ecr	thermoelectric sensor (thermocouple) type R (-40 ÷ 1,600°C)	
	tc-t	thermoelectric sensor (thermocouple) type T (-25 \div 350°C)	
	£c-6	thermoelectric sensor (thermocouple) type E (-25 ÷ 820°C)	